

WARNING

This information is a copy of an original archive, therefore Aga cannot be held responsible for its continued accuracy.



RAYBURN

Home on the Range.

Installation Instructions for Rayburn Nouvelle Solid Fuel and Wood Burning Cooker

Consumer Protection Act 1987

As manufacturers and suppliers of cooking and heating products, in compliance with Section 10 of the Consumer Protection Act 1987, we take every care to ensure, as far as is reasonably practicable, that these products are so designed and constructed as to meet the general safety requirement when properly used and installed. To this end, our products are thoroughly tested and examined before despatch.

IMPORTANT NOTICE: Any alteration that is not approved by Aga-Rayburn, could invalidate the approval of the appliance, operation of the warranty and could also affect your statutory rights.

Control of Substances - Health and Safety Important

This appliance may contain some of the materials that are indicated below. It is the Users/Installers responsibility to ensure that the necessary personal protective clothing is worn when

handling, where applicable, the pertinent parts that contain any of the listed materials that could be interpreted as being injurious to health and safety, see below for information.

Firebricks, Fuel beds, Artificial Fuels - when handling use disposable gloves.

Fire Cement - when handling use disposable gloves.

Glues and Sealants - exercise caution - if these are still in liquid form use face mask and disposable gloves.

Glass Yarn, Mineral Wool, Insulation Pads, Ceramic Fibre, Kerosene Oil - may be harmful if inhaled, may be irritating to skin, eyes, nose and throat. When handling avoid inhaling and contact with skin or eyes. Use disposable gloves, face-masks and eye protection. After handling wash hands and other exposed parts. When disposing of the product, reduce dust with water spray, ensure that parts are securely wrapped.

PERFORMANCE

The Rayburn Nouvelle is intended to supply heating for:-

- (a) Cooking and domestic hot water.
- (b) Cooking, domestic hot water and central heating.

Air for combustion within the firebox is obtained from two sources viz:-


- a) When the appliance is being used for cooking and domestic hot water only, the rate of burning is determined by the manually operated spinwheel control on the ashpit door.
- b) When central heating is also required, close the spinwheel control and operate the burning rate by means of the boiler thermostat.

The cooker has both boiler and cooker flues which are opened/closed by internal dampers working in conjunction and operated manually by the cooker/boiler damper at the front of the cooker.



The setting should be relative to the services required, viz:- **H** for all services, **C** for cooking and domestic hot water only.

WARNING


THE ASHPIT AND FIREBOX DOORS MUST BE LOCKED CLOSED AT ALL TIMES DURING NORMAL USE, EXCEPT WHEN LIGHTING OR RE-FUELLING.



DESN 510291



DESN 510278



	A	B	C	D
	mm	mm	mm	mm
Combustible	150	150	150	225
Non-combustible	150	*100	*100	225

*Dimensions 'B' & 'C' may be zero if installed against non-combustible wall 200mm thick or over.

Fig.1

DESN 510279

RATINGS - Burning Solid Fuel

Winter Use See Para. re: Firebrick Positions

The maximum boiler output obtainable burning solid fuel at the optimum burning rate - with the cooker/boiler damper knob at **H** and the boiler thermostat at No.8 - is 16.12kW (55,000 Btu/h). This will provide for 29.89m of radiator surface and pipework plus domestic hot water or 32.24m of radiator surface and pipework only. The recommended heating surfaces indicated are based on an average heat emission of 0.5kW/m (160 Btu/h/ft). When cooking only, with the cooker/boiler damper knob at **C** and oven at a steady 230°C (450°F), the water output reduces to 5.6kW (19,000 Btu/h). Overnight banking with the cooker/boiler damper knob at **C** will produce 2.3kW (8,000 Btu/h) of hot water from the boiler.

Summer Use See Para. re: Firebrick Positions

With the cooker/boiler damper knob at **C** and the oven temperature maintained at a steady 200°C (390°F) the hot water output from the boiler will be 3.1kW (10,500 Btu/h). Overnight banking with the cooker/boiler damper knob at **C** will produce 1.9kW (6,900 Btu/h) of hot water from the boiler.

RATINGS - Burning Wood

Winter Use: To obtain the optimum burning rate with the wood burning fuels only, a grate baffle should be located on the top face of the reciprocating bars at the rear of the firebox. See diagram.

Grate riddling is not required when burning wood where poking will normally suffice.

Always remove this grate baffle when burning solid fuels.

See Para. re: Firebrick Positions

The maximum boiler output obtainable burning wood logs at the optimum burning rate - with the cooker/boiler damper knob at **H** and the boiler thermostat at No.8 - is 10.26kW (35,000 Btu/h). This will provide for 18.17m² (194ft²) of radiator surface and pipework plus domestic hot water 20.52m² (219ft²) of radiator surface and pipework only. Overnight banking with the cooker/boiler damper knob at **C** will produce 1.46kW (5,000 Btu/h) of hot water from the boiler.

Summer Use See Para. re: Firebrick Positions

With the cooker/boiler damper knob at **C** and the oven maintained at roasting temperature the hot water output from the boiler will be 2.6kW (9,000 Btu/h) of hot water from the boiler.

Overnight banking with the cooker/boiler damper knob at **C** will produce 1.46kW (5,000 Btu/h) of hot water from the boiler.

PREPARATION OF SITE

The non-combustible hearth must be solid and level and together with the walls adjacent to the cooker and chimney, conform to current Building Regulations.

The cooker and chimney flue installation should be in accordance with the relevant recommendations of the British Codes of Practice BS 8303, BS.6461 Part 1 and BS 7566 Parts 1 to 4 respectively and the central heating system to BS.5449 Part 1. The boiler installation section must also be in accordance with the byelaws of the local Water Undertaking, Regulations for the Electrical Equipment of Buildings-published by the Institute of Electrical Engineers and any relevant requirements of the Local Authority.

Ensure that any electrical wiring is correctly earthed. Where the cooker is to stand in a recess or against a wall which is to be tiled, in no circumstances should the tiles overlap the cooker top plate.

COOKER POSITION

When the cooker is installed in a recess it must be 'freestanding' and not built-in solid at the sides. Ensure that any combustible material e.g. kitchen furniture is spaced away from the cooker to the recommended distances. See Fig. 1.

Tiling

Where the cooker is to stand in a recess or against a wall which is to be tiled, **in no circumstances should the tiles overlap the cooker top plate.**

BUILDERS OPENING

For 200mm thick non-combustible or new recesses, an opening of 1,080mm wide minimum, by 343mm deep minimum and 1,680mm high minimum from floor is recommended.

THE CHIMNEY

Checking existing chimney

The internal and external condition of the chimney should be checked **before** the appliance is installed and rectification made where necessary to prevent leakage or porosity. The soundness of the chimney which should have a minimum flue dimension of 175mm square or 185mm diameter can be confirmed by smoke testing. Advice on the test method can be obtained from HETAS.

When repairing or re-using existing chimneys its recommended that the building control office be consulted before the commencement of work with particular attention to the chimney height and its termination.

The chimney must be swept before installation.

Erecting New Chimney

The flue through the chimney should be formed with pre-cast moisture and acid resistant liners with a minimum internal dimension of 185mm square and all in accordance with the current Building Regulations (England and Wales) and in Scotland the Building Standards (Scotland) (Consolidation) Regulations and the Codes of Practice for chimneys and flues BS.6461 Part 1 and BS 7566 Parts 1 to 4. Ensure the chimney liners are free of projecting internal building jointing composition before the appliance is installed.

Factory made Insulated Chimneys

It is recommended the chimney be ceramic lined and comply with BS.4543.

The minimum diameter for a straight chimney is 175mm and if offsets are fitted the recommended minimum diameter is 200mm.

IN ALL TYPES OF CHIMNEYS THE MINIMUM HEIGHT FOR PROPER OPERATION OF THE COOKER IS 5.5m AND SHOULD TERMINATE ABOVE THE ROOF IN ACCORDANCE WITH REGIONAL STATUTORY REQUIREMENTS. RECOMMENDED FLUE DRAUGHT-2mm W.G. (0.08in) MINIMUM. THE APPLIANCE SHOULD BE INSTALLED AND CONFORM TO THE CURRENT CODES OF PRACTICE FOR INSTALLATION OF DOMESTIC HEATING AND COOKING APPLIANCES BURNING SOLID FUEL -BS 8303.

ALWAYS ADVISE THE USER TO CLEAN THE COOKER FLUES IN ACCORDANCE WITH THE OPERATING INSTRUCTIONS AND TO HAVE THE CHIMNEY SWEEPED AT A MINIMUM OF 12 MONTHLY INTERVALS AFTER THE COOKER IS COMMISSIONED.

COOKER FLUE CONNECTION

The position of available types of flue layouts are shown in Figs 2, 3 and 4, the cooker flue chamber is adaptable to provide either top or back flue outlets, by means of the reversible loose socket.

(a) Rear Flue Outlet

This must only be used where there is a brick flue immediately behind the cooker. Provision must be made for a condensate collecting vessel and cleaning door. See Fig.3.




Fig. 2

DESN 510281




Fig. 3

DESN 510282




Fig. 4

DESN 510283

NOTE: EXTENDED REAR FLUE PIPE AND BENDS ARE NOT RECOMMENDED.

(b) **Top Flue Outlet**

The cooker should be connected to the main flue via a 150mm minimum diameter cast iron pipe or appropriately internally externally vitreous enamelled mild steel pipe and be sealed to the cooker flue chamber with soft rope and fire cement.

Any bends in the flue pipe must be not less than 135° (45° from horizontal) and be complete with a cleaning door.

FLUE LAYOUTS

In Fig.2. the cooker is installed in an existing recess. There must be a clearance of not less than 150mm between the top of the flue pipe and any overhanging brickwork.

Any cavities or pockets above the register plate should as far as possible be filled and if necessary the flue pipe should be extended into the throat of the chimney and soot door provided for chimney sweeping.

If a flue liner or insulated chimney is used, the size should not be less than 185mm square or 225mm diameter, and 175mm diameter respectively.

In Fig.3. the cooker is connected direct to a brick flue. Horizontal pipe runs between cooker and brick flue **must not** be used.

In Fig.4 the cooker is connected to an existing brick flue with a length of flue pipe. Square bends and horizontal runs **must not** be used. There must be a cleaning door at every bend.

NOTE: WHATEVER METHOD OF INSTALLATION IS EMPLOYED, AIR MUST NOT BE ALLOWED TO ENTER THE CHIMNEY EXCEPT THROUGH THE COOKER. ALL JOINTS MUST BE AIR-TIGHT.

If the chimney is unlined, and there is any doubt about its condition, it should be lined in accordance with current Building Regulations .

PROVISION MUST ALWAYS BE MADE FOR SWEEPING THE CHIMNEY.

IMPORTANT: CEMENT TYPE PIPES AND FITTINGS MUST NOT BE USED WITHIN 2m. OF COOKER. CHIMNEYS OF PLAIN PIPE ARE NOT RECOMMENDED BUT CERTAIN PROPRIETARY MAKES OF INSULATED CHIMNEY ARE SUITABLE.

AIR SUPPLY

Provision must be made for a permanent unobstructed air vent having a minimum effective area of 182.5cm² (28.25sq in) communicating directly to outside air or an adjacent room which itself has a permanent air vent of at least the flue size direct to outside air.

Effect of Extractor Fan

Avoid if possible the installation of an extractor fan in the same room as the cooker. Compensating extra air inlets must be introduced equivalent to the capacity of the fan when fitted.

CENTRAL HEATING AND HOT WATER SYSTEM

It is recommended that a 190 litre (40galls) indirect hot water storage cylinder of the double feed type e.g. (Manufactured by Albion Cylinders, complying with BS.1566 Part 1:DF Type 10 should be lagged and fixed vertically as near as possible to the cooker.

The 28mm minimum diameter primary flow and return pipes must not exceed 10m in length and pipes longer than 5m must be lagged.

Ensure that the flow pipe has an open vent and rises continuously from the boiler to the cylinder to ensure good gravity circulation.

In combined systems, the water draw-off pipes to the taps must be dead-leg connection from the vent/expansion pipe.




Fig. 5 Typical Central Heating/Hot Water System

DESN 510284




Fig.6 Typical Wiring Diagram

DESN 510285

There are only two boiler tappings on this cooker and a typical design layout is shown in Fig.5.

An injector tee is provided which must be fitted to ensure adequate primary flow circulation when the water circulator is operating, otherwise there may be a lack of domestic hot water.

The heating flow and return pipes may be 22mm, the return pipe being connected to the 28mm primary return by the injector tee, and the tee outlet connected to the boiler return pipe.

All installations must be fitted with a drain tap at the lowest point of the system.

BOILER - Control

In order to maximise the life of your boiler body, an electrical thermal re-set low temperature boiler thermostat has been fitted within the appliance, behind the L.H. side removable cover, whose purpose is to isolate electrical power from the water circulator when the boiler temperature falls below 60°C (140°F) and thus minimise harmful condensation on the boiler surfaces. The 3 core 0.75mm² cable lead from the appliance must be connected to/from the water circulator as indicated on the 'Typical Wiring Diagram' in Fig.6.

NOTE: IF THERE IS A POSSIBILITY OF BOILING TAKING PLACE, A REVERSE ACTING THERMOSTAT SHOULD BE FITTED TO THE DOMESTIC HOT WATER CYLINDER OR BOILER PRIMARY FLOW PIPES, AND ELECTRICALLY CONNECTED TO THE CENTRAL HEATING PUMP. THIS WILL SWITCH THE PUMP 'ON' TO PREVENT BOILING.

HIGH UPDRAUGHTS

Tall chimneys may develop excessively high updraughts which prevent the appliance operating correctly.


It is recommended that a proprietary brand adjustable flue draught stabiliser having an openable cross sectional area of 182.5sq cm (28.25sq in) be fitted above the flue pipe connection, either in the brickwork or into a right-angle 'T'; fitting in the flue pipe position that will not inconvenience appliance operation or maintenance.

GENERAL - Firebrick Positions and Replacement


The Rayburn Nouvelle is delivered complete including a set of boiler removable firebricks where positional location determines the amount of hot water supplied in winter and summer seasons.

The oven side and firebox front firebricks are permanently fixed with fire cement whilst the two boiler face side bricks and boiler back brick are located for the summer season thereby providing domestic hot water only. For winter use or central heating facilities, the boiler face rear brick is removed and the boiler face side bricks are transferred to locate on/over the oven side firebricks. See diagram 7.

The firebricks fitted to Rayburn Cookers are of first quality manufacture, and providing the cooker has been installed and used correctly will have a reasonable life. There are, however, expendable items and in time will require renewal. The renewal of firebricks is not a major operation and can be carried out by the average handyman. Replacement bricks either in sets or singly can be obtained from you Rayburn distributor. Quote the serial number which will be found on the fire door dataplate.



WINTER USE (DOMESTIC HOT WATER & CENTRAL HEATING) SIDE FIREBRICKS 'A' MOUNTED IN RIGHT HAND SIDE OF FIREBOX OVER PERMANENTLY FIXED OVEN SIDE FIREBRICKS, & REAR FIREBRICK 'B' REMOVED.



SUMMER USE (DOMESTIC HOT WATER ONLY) SIDE FIREBRICKS 'A' MOUNTED IN LEFT HAND SIDE OF FIREBOX & REAR FIREBRICK 'B' IN POSITION.

INSTALLATION

Place the cooker in the intended position and lift out the surface ground hotplate, checking that the joint between the underside of the hob and the top of the cooker are intact. Any joints which have opened should be made good with fire cement provided.

Check that the boiler/cooker flueway dampers operate correctly by turning the knob on the front plate adjacent to the top left hand corner of the roasting oven door.


NOTE: IT IS NOT VISUALLY POSSIBLE TO SEE THE BOILER DAMPER AND THIS SHOULD BE CHECKED BY FEELING THROUGH THE HOTPLATE APERTURE TO THE BACK OF THE COOKER. THE COOKER DAMPER SPINDLE OPERATES THE BOILER DAMPER WHICH CAN BE FELT BY INSERTING HAND INTO BOILER FLUEWAY.

Replace the hotplate making sure that it is seating evenly on the soft rope and that it is approximately 1.5mm proud of the enamelled top plate, with an equal space all round.

1. Connect pipework to boiler flow and return tappings.
2. Fit the Flue Chamber which should be given a 1mm smear of fire cement on the underside then screwed to the cooker. Make sure there is a good seal between the flue chamber and the cooker top (if there is an ingress of air it can affect the flue draught and proper working of the cooker). Before the fire cement hardens remove any surplus with a damp cloth then polish with a dry cloth. Failure to do so can result in the enamel surface being permanently marked.
3. Open the firebox and ashpit doors and check that the reciprocating bottomgrate bars are in position. Operate the riddling lever to ensure correct bottomgrate operation.
4. Turn the boiler thermostat knob at the rear left hand corner of the top plate from No.1 (low) to No.8 (high).

NOTE: THE HIGHER THE NUMBER, THE HIGHER THE WATER TEMPERATURE.

The handrail brackets are held on the front ends of the cooker top-plate casting. Remove the travel nuts and replace with the handrail brackets ensuring the fibre protecting washers are in position. Insert the handrail into the brackets, positioning them correctly, and tighten the locating bolts (Fig.8).



TESTING AND COMMISSIONING

After completing the installation, the Heating Contractor should demonstrate to the user, the operation of the appliance and the routine flue cleaning method.

Check that the system is full of water and free from air locks.

When lighting pull the flue chamber damper open to maximum, add paper and sticks with a small quantity of fuel through fuelling aperture onto bottomgrate and close the firebox door.

Open ashpit door, ignite fuel and close ashpit door when fuel is well alight with boiler thermostat knob or spinwheel on ashpit door at required setting.

Allow the cooker to heat up gradually at first time lighting.

With Aga-Rayburn's policy of continuous product improvement, the Company reserves the right to change specifications and make modifications to the appliance described and illustrated at any time.

Rayburn

Manufactured by

Aga-Rayburn

PO Box 30 Ketley Telford Shropshire TF1 4DD

Telephone (01952) 642000 Fax (01952) 641961



Aga-Rayburn A member of the Glynwed International plc group of companies

Operating instructions. Rayburn Nouvelle Solid Fuel and Wood Burning Cooker

Health & Safety at Work Act 1974

As manufacturers and suppliers of cooking and heating products, in compliance with Section 6 of the Health & Safety at Work Act 1974, we take every care to ensure, as far as is reasonably practicable that these products are so designed and constructed as to be safe and without risk to health when properly used and installed. To this end, our products are thoroughly tested and examined before despatch. THE USER SHOULD OBTAIN CONFIRMATION FROM THE INSTALLER THAT THE CHIMNEY IS OF SOUND AIRTIGHT CONSTRUCTION, IS CLEAR OF OBSTRUCTIONS AND HAS BEEN SWEEPED BEFORE INSTALLATION.

Introduction

The Rayburn Nouvelle has been designed to burn a variety of solid fuels and thereby provide heating facilities for cooking, domestic hot water and central heating.

The thermostatically controlled hot water boiler can be operated independently of the cooker and will provide hot water for central heating and domestic use (normal setting for winter usage), whilst manually operated spinwheel control on the front of the ashpit door will provide heat for cooking and domestic hot water (normal setting for summer usage).

The cooker/boiler flueway damper knob on the centre front of the cooker below the top plate requires to be set in conjunction with the flue chamber damper to obtain the appropriate service required from the appliance.

1. Preparing Cooker for Use Firebrick Positions

The Rayburn Nouvelle is delivered complete including a set of boiler removable firebricks where positional location determines the amount of hot water supplied in winter and summer seasons.

The oven side and firebox front firebricks are permanently fixed with fire cement and should remain in their positions at all times.

The two boiler face side bricks and boiler face rear brick are so located for summer use when hot water, for domestic use only, will be provided.

For winter use or central heating facilities the boiler face rear brick is removed and the two boiler face side bricks are transferred to locate on/over the oven side bricks.

Secondary Air Slide

On opening the firedoor the secondary air slide is seen on the base of the opening and should be set according to the fuel being used as follows:—

Air Slide Open —

ALL fuels except Sunbrite Coke

Air Slide Closed —

SUNBRITE Coke only


2. Recommended Solid Fuels

MANUFACTURED — SUNBRITE SINGLES, SUNBRITE DOUBLES, COALITE, PHURNACITE, REXCO and ROYAL

NATURAL — ANTHRACITE STOVE NUTS, WELSH DRY STEAM COAL (LARGE NUTS), SELECTED HOUSECOAL (TREBLES/LARGE NUTS and DOUBLES/NUTS).

Oversize fuel lumps should be broken down to size. Stone and other foreign bodies should be removed when fuelling.


Fuel should be stored under cover, particularly manufactured fuels which must be kept dry. Wet kitchen refuse should not be burned.




3. Fuelling with Wood or Peat

The cooker will satisfactorily burn wood logs, blocks or peat briquettes, but the logs should be perfectly dry in order to obtain the best cooker performance and minimise the deposits of creosote. Wet logs may also provide overnight banking problems and the following hints are recommended:—

- Burn dry soft wood in the day time and dry hard wood overnight if possible.
- Avoid using 'green' wood on overnight banking as creosote deposits will be increased.
- Using hard wood in the daytime will give prolonged burning but heating response is slower.
- Wet kitchen refuse should not be burned.
- Before refuelling, open the flue chamber damper to its full extent and fill the firebox up to the bottom of the firedoor opening, ensuring the secondary air slide is at fully open.
- To obtain the optimum burning rate with wood burning fuels only, a grate baffle should be located on the top face of the reciprocating bars at the rear of the firebox. See Diagram. Grate riddling is not required when burning wood where poking will normally suffice. Always remove this grate baffle when burning solid fuels.



4. Familiarise Yourself with the Cooker



5. Lighting the Fire — All Fuels Using Wood and Paper.

- Check the flue pipe is free of blockage.
- Open firebox door.
- Open ashpit door.
- De-ash (Fig. 3) and remove dead fuel from bottomgrate (lift off clinker door above the bottomgrate (Fig. 5), rake fuel into ashpan, replace clinker door).
- Remove ashpan, empty and replace (Fig. 4).
- Open flue chamber damper to maximum (Fig. 2).
- Flue dilution lever fully to 'left' (flue chamber door closed, Fig. 2).
- Lay a liberal supply of wood and paper on top of the bottomgrate bars together with a small quantity of fuel and light.
- Close and lock the ashpit door with the spinwheel control open.
- Close and lock the firedoor.
- With fire established, open firebox door and fill firebox with fuel. Check secondary air slide setting (Fig. 1). Close and lock firebox door. Push flue chamber damper back to position which has been found to give desired burning rate.

6. Lighting the Fire — All Fuels Using a Gas Poker

- Check flue pipe is free of blockage.
- Open firebox door.
- Open ashpit door.
- De-ash (Fig. 3) and remove clinker door (Fig. 5). Insert flat bayonet type gas poker on top of bottomgrate bars.
- Remove ashpan and empty (Fig. 4).
- Open flue chamber damper to maximum (Fig. 2).
- Flue dilution lever fully to 'Left' (flue chamber door closed, Fig. 2).
- Lay a 75–100mm (3"–4") shallow depth of fuel onto the bottomgrate and light gas poker.
- Close the ashpit and firebox doors as far as possible — spinwheel control open.
- When the fuel is well alight, extinguish and remove the gas poker, replace the clinker door and ashpan, close and lock the ashpit door with the spinwheel control open, close the firedoor.
- With the fire established, open the firebox door and fill firebox with fuel. Check secondary air slide setting (Fig. 1). Close and lock the firebox door. Push the flue chamber damper back to position which has been found to give best results. Set spinwheel control to give desired burning rate.

7. Cooker Control — Cooking Only — All Fuels

- The fire is controlled by using the spinwheel on the ashpit door to govern the air supply.
- The adjustable flue chamber damper is for reducing the chimney draught, and the more it can be closed, the easier the cooker is to control. The line markings on the flue chamber damper enable you to repeat the best settings to suit your chimney, from No. 1 in a closed position to No. 6 when fully open.
- Control over the direction of the flue gases is obtained by the setting of the cooker/boiler damper. Set the cooker/boiler damper knob on front of the cooker to 'C' and the boiler thermostat knob on the rear left hand corner of the top plate, to its minimum setting.
- Thermostat set at No. 1 as domestic hot water is obtained when cooking.

NOTE: INTERMEDIATE SELECTIVE SETTINGS OF THE COOKER/BOILER DAMPER KNOB AWAY FROM 'C' WILL PROGRESSIVELY RESTRICT THE AMOUNT OF HEAT TO THE TOP OF THE OVEN AND INCREASE THE AMOUNT OF HEAT INTO THE BOILER UNTIL THE KNOB IS POINTING TO SYMBOL 'H' FOR MAXIMUM WATER HEATING. IN THIS POSITION, THE MINIMUM PROPORTION OF HEAT IS DIRECTED TO OVEN HEATING.

8. Control Setting — Cooking Only — All Fuels

Set spinwheel open which does not require to be open more than:—

- Coke — Five complete turns.
- Other recommended fuels — Three complete turns during cooking periods.

After setting the cooker/boiler damper knob to 'C', set the flue chamber damper fully open after re-fuelling and reset to position which has been found by practical experience to give the best results. Do not try to obtain a fast increase in temperature by opening flue chamber damper to its fullest extent. This results in most of the heat being wasted up the chimney.

Avoid excessive fire temperatures with solid fuel—they are unnecessary and may do serious harm to the cooker.

The first symptoms of an overheated cooker is the formation of clinker (melted ash) which will damage the firebricks.

Damaged firebricks should be replaced as soon as possible but may be temporarily repaired with fire cement.

Keep the ashpit door securely closed with the front plate catch.




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5

9. Overnight Banking (Solid Fuel)

The appliance is designed for continuous burning and the best results will only be obtained if it is allowed to burn overnight. It is no more expensive in fuel costs.

Last thing at night, de-ash the fire, empty the ashpan and fully refuel but do not overload.

Ensure that the firebox and ashpit doors are securely closed, and after closing the spinwheel, re-open it a quarter of a turn.

Set the boiler thermostat knob to its minimum setting and close the flue chamber damper plate to No. 1 setting. Set the cooker/boiler damper knob to 'C' to obtain optimum heat into oven and hot plate.

NOTE: THE BEST POSITION FOR THE FLUE CHAMBER DAMPER CAN BE FOUND ONLY BY EXPERIMENT BUT ALWAYS TRY THE LOW SETTING FIRST.

In the morning, open the spinwheel three complete turns, the flue chamber damper to maximum and riddle the fire. When it is burning brightly, close the flue chamber damper, but do not refuel before use if the hotplate is required immediately.

10. Boiler Central Heating Thermostat Setting-All Fuels.

Set the cooker/boiler damper knob to 'H'.

Close spinwheel.

To regulate burning, set the boiler thermostat knob to '8' (high) or minimum rate '1' (low).

Adjust as required to suit desired water heating.

Overnight banking and daytime slow burning should be obtained with the boiler thermostat knob set at '1' to give extended burning.

Woodburning

Some woods are more difficult to burn therefore it may be necessary to open the spinwheel in addition to the thermostat to obtain the desired results. The spinwheel must be closed as appropriate.

11. Overnight Central Heating – Solid Fuel Only

The appliance may be operated overnight for the purpose of selected central heating when inclement weather conditions occur.

Set the cooker/boiler damper knob to 'H' after refuelling etc. and the boiler thermostat knob to No. 2 with the flue chamber damper set at minimum. The spinwheel should be closed and about four radiators can be run overnight under these conditions.

NOTE: THE HOTPLATE AND OVEN TEMPERATURE WILL BE CONSIDERABLY LOWER AND EXTENDED TIME WILL BE NEEDED TO HEAT UP THESE FEATURES. DO NOT FORGET TO RE-SET THE COOKER/BOILER KNOB TO 'C' FOR COOKING AFTER OVERNIGHT USE.

12. Overnight Banking – Wood

The appliance is designed for continuous slumbering overnight for up to a maximum of 12 hours depending on the type of dry wood being used. Last thing at night, open the flue chamber damper, de-ash the fire, empty the ashpan and fully refuel.

Ensure that the firebox and ashpit door are securely closed, close the spinwheel tight and the flue chamber damper is set to No. 1.

Set the boiler thermostat knob to its minimum setting and the front damper knob to 'C'.

Turn the flue dilution lever (See Fig. 2) from left to right hand so that the flue chamber door opens at the bottom and minimises burning rate.

NOTE: THE PRECISE AMOUNT OF OPENING DEPENDS ON THE CHIMNEY DRAUGHT, THE TYPE/CONDITION OF WOOD TO BE BURNT AND THIS MAY TAKE 2 OR 3 DAYS TO ASCERTAIN.

1. If the fuel in the firebox is exhausted prematurely, the overnight chimney draught must be reduced by increasing the opening setting of the flue chamber door, using the flue dilution lever.

2. If the fuel does not burn but 'dies out', the draught should be increased by reducing the opening setting of the flue chamber door, using the flue dilution lever.

Following overnight banking, the flue chamber door must be closed, the spinwheel and flue chamber damper opened and the fire refuelled.

Immediately the new fuel has caught alight, riddle the fire and close the flue chamber damper.

NOTE: BUILD-UP OF CREOSOTE DEPOSITS IN THE FLUE AND CHIMNEY CAN IN TIME, LEAD TO CHIMNEY FIRES.

THESE DEPOSITS CAN BE PREVENTED BY THE REGULAR USE OF A PROPRIETARY BRAND OF CHEMICAL CREOSOTE REMOVER CHIMNEY CLEANER SUCH AS "ATTACK" WHICH REDUCES THE ADHESION STRENGTH OF THE CREOSOTE DEPOSITS, CAUSING THEM TO FALL.

IMPORTANT: CHEMICAL CLEANERS MUST NOT BE CONSIDERED AS AN ALTERNATIVE TO CHIMNEY SWEEPING, ONLY AS SUPPLEMENTARY.

13. Typical Water Temperatures against Thermostat Knob Settings with Cooker/Boiler Damper at 'H' and Spinwheel closed.

Thermostat Setting No.	Water Temperature
1	46°C (115°F)
3	54.5°C (130°F)
5	65.5°C (150°F)
8	80°C (176°F)

a) Using the cooker boiler to provide heat for domestic hot water and radiators in the winter, a boiler thermostat setting at No. 8 is recommended.

b) Using the cooker boiler for the provision of domestic hot water only, in the summer, a boiler thermostat setting of No. 5 is recommended.

NOTE: TO CONSERVE FUEL, ENSURE THE HOT WATER CYLINDER AND PIPES ARE LAGGED WITH INSULATION.

14. Refuelling

The firebox should be filled to the recommended level of the bottom firebox door opening and the firebox door closed.

A correctly fully fuelled fire will last a minimum of 2 hours when burning solid fuel and 1 hour burning wood when maintaining the maximum rated output of the boiler with intermittent cooking periods included.

NOTE: When burning all recommended fuels other than Sunbrite Coke, the secondary air slide should be set in a fully open position.

A deep bed of newly charged fuel on a low fire will take time before heat reaches the oven, hotplate and boiler. When burning Coal, Phurnacite and Anthracite, allow several minutes for the new charge to ignite before changing the flue chamber damper setting. Once refuelling has been completed, close the firebox door immediately and open only for refuelling charges.

15. De-Ashing

To de-ash, riddle the grate by agitating the riddling handle in an up and down manner about 20 times to free the grate of ash. See Fig. 3.

ALWAYS DE-ASH BEFORE REFUELLING (SEE 'EXCEPTIONS' BELOW) AT THE FOLLOWING INTERVALS:—

SUMMER USE:

Three times daily at least.

WINTER USE:

Three times daily at least and more often if required.

NOTE: SHOULD THE BOTTOMGRATE DE-ASHING FAIL TO CLEAR AN ACCUMULATION OF STONES, SHALE OR CLINKER, IT MAY BE REMOVED AS DESCRIBED IN SECTION ON REMOVAL OF CLINKER.

Open the ashpit door to give access to the ashpan which must be emptied regularly (See Fig. 4).

In winter, this may be as much as three times daily depending on weather severity.

The class of fuel and cooker usage govern the frequency of refuelling.

NOTE: DO NOT ALLOW ASH TO ACCUMULATE IN THE ASHPAN UNTIL IT TOUCHES THE UNDERSIDE OF THE BOTTOMGRATE BARS OR THEY WILL QUICKLY BURN OUT.

Ensure the ashpan is fully home otherwise the ashpit door may not close and lock completely.

EXCEPTIONS:

WHEN BURNING ANTHRACITE OR PHURNACITE, ALWAYS REFUEL BEFORE EMPTYING ASHPAN AND RIDDLING.

16. Removal of Clinker from Bottomgrate

Due to an accumulation of pieces of stone, clinker and shale etc. it may not be possible to pass them through the grate when riddling, and may even cause jamming.

Allow the fire to burn out and then open the ashpit door. Lift off the clinker door (See Fig. 5) and insert hooked poker to draw out any offending accumulation. Replace clinker door after use.

The amount of clinker formation is dependent on the heating load or burning rate and should be checked weekly for any build-up. Excessive build up will lead to a fall off in heating output requiring bottomgrate clean-out and reduction in life of the bottomgrate.

17. Use of the Hot Plate

The best results can only be obtained by using machined base utensils. The hottest part of the hot plate is immediately above the fire, the other end being for simmering.

The circular plug in the hotplate (near the flue chamber end) is for flue cleaning and must not be removed for cooking.

Keep the hotplate clean with a wire brush.

NOTE: TO OBTAIN OPTIMUM HOTPLATE PERFORMANCE FOR FAST BOILING OR HOT PLATE COOKING, FUEL THE FIREBOX TO THE BOTTOM EDGE OF THE FIREBOX APERTURE TO A HORIZONTAL LEVEL.

WARNING: THE COOKER TOP PLATE SURFACE AROUND THE HOTPLATE WILL BECOME HOT UNDER USE AND CARE MUST BE OBSERVED.

18. Use of the Top Roasting Oven

The correct adjustment of the spinwheel and flue chamber damper to obtain the oven temperature required varies with the chimney draught, and can be found only by experiment. The following is a suggested method only, and may need modification to suit local conditions.

Suppose an oven temperature for roasting is desired, and that the cooker is idling.

Thoroughly de-ash the fire as described in the respective paragraph, and refuel. Set the flue chamber damper to No. 3 setting and open the spinwheel as described under 'CONTROL SETTING'.

As soon as the fire has become red all through, close the flue chamber damper. Do not allow the fire to become white hot.

The temperature of the oven should now rise steadily. When it reaches a point about 30° C (90° F) below that required, close the spinwheel to approximately one turn open. Thereafter control the temperature of the oven by adjusting the spinwheel.

NOTE: THIS METHOD SHOULD PROVE SUCCESSFUL IN ALMOST ALL CASES, BUT IF CLOSING THE FLUE CHAMBER DAMPER CAUSES THE FIRE TO SMOKE, IT SHOULD BE OPENED GRADUALLY UNTIL THE SMOKING STOPS.

To reduce top heat in the oven adjust the cooker/boiler damper knob gradually away from symbol 'C'. The oven may be cleaned with a stiff wire brush, when it is very hot.

OVEN TEMPERATURES:—

HOT

200° – 260° C (400° – 500° F)

MODERATE

150° – 200° C (300° – 400° F)

SLOW

90° – 150° C (200° – 300° F)

Check with pointer reading on oven door thermometer.

19. Use of the Bottomgrate Cooking Oven

It is not possible to control this oven, but during the course of roasting, sufficient heat input permits simmering of dishes that have been taken from the roasting oven.

OVEN TEMPERATURES:—

Idling – 95° C min.

During cooking – 135° C max

During the cooker idling periods, the oven is ideal for heating plates and keeping food warm.

NOTE: TAKE CARE WHEN CLOSING ALL FRONT DOORS TO LIFT THEM ON TO THE CATCH. THE DOORS SHOULD NOT BE SLAMMED SHUT OR THIS WILL WEAR AWAY THE METAL RETAINING CATCHES.

20. Flueway Cleaning

When burning coke, anthracite, other smokeless fuels, logs or peat, the appliance flueways should be cleaned on a regular four weekly basis.

When burning bituminous coal, cleaning should be done at weekly intervals.

Failure to ensure clean flueways, flue pipes and bends may lead to emission of dangerous gases and an inferior performance from your appliance.

Cooker Flueway: Allow the fire to burn out, open the flue chamber damper to its maximum and remove the flue chamber door.

Turn the cooker/boiler knob to 'C'.

Brush the soot or fly ash from the flue pipe allowing it to fall onto the top of the oven. Fig. 6.

Remove the hotplate plug and rake the deposits forward, pushing them into the firebox. Figs. 7&8.




Fig. 6




Fig. 7




Fig. 8




Fig. 9

Boiler Flueway: Set the cooker/boiler damper knob to 'H', and remove boiler cleaning cover in top plate adjacent to boiler thermostat control knob. Lift out exposed boiler cleaning plate and brush rear boiler flueways up and down allowing debris to fall into the firebox. Fig. 9. Clean boiler flue outlet by inserting brush horizontal at right hand of boiler aperture below top plate. Push brush above and below the boiler damper so that flyash etc. is pushed onto oven top. Insert rake through hotplate plug aperture and pull deposits into firebox (after re-setting cooker/boiler damper knob to 'C'). Replace flue chamber door and hotplate plug and riddle the bottomgrate thoroughly to clear the bottomgrate ready for relighting.

NOTE: THE APPLIANCE IS DESIGNED AND INTENDED TO BE UNDER CONTINUOUS FIRING BUT IF IT IS NOT IN USE' ASHPIT AND FLUE CHAMBER DOORS SHOULD BE LEFT OPEN TO ENSURE FREE PASSAGE OF AIR THROUGH THE APPLIANCE AND AVOID CONDENSATION PROBLEMS.

21. Chimney Sweeping
Sweep annually and inspect soot box at 3 monthly intervals and remove any deposits.

NOTE: SWEEPS BRUSHES MUST BE OF THE TYPE WITH WIRE CENTRES AND GUIDE WHEELS.

22. Cleaning
Surface blemishes caused by spillage on the gloss enamel are easier to remove when the cooker is cool, and a damp cloth is usually all that is necessary. This should not be done whilst the cooker is hot.

23. To Replace Bottomgrate Bars
Allow fire to burn out first then open the ashpit door and lift off the clinker door. Remove dead fuel with hooked poker into ashpan and then lift up each individual bar, pulling forward to remove.

NOTE: THERE ARE TWO TYPES OF BARS ASSEMBLED AND THE REPLACEMENT BAR SHOULD BE CHECKED AGAINST 'REPLACED' BAR BEFORE REPLACEMENT.

24. Firebrick Replacement
The firebricks fitted to the Rayburn Nouvelle are of first quality manufacture, and providing the cooker has been installed and used correctly will have a reasonable life. They are, however, expendable items and in time will require renewal. Replacement bricks either in sets or singly can be obtained from your Rayburn distributor. Always quote the manufacturing number. The manufacturing number, which will be found on a brass plate inside the roasting oven, should be quoted if any question arises in connection with the Rayburn Nouvelle Cooker.

25. Hot Water Service
The cooker has been designed to provide a satisfactory supply of domestic hot water with or without a limited amount of heating with a normal day's cooking providing the cooker is kept alight overnight and the system complete with lagged cylinder conforms to the installation instructions.

26. Servicing
Always use a qualified service/ heating engineer when servicing is required.


27. Fume Emission Warning
Properly installed and operated, this cooker will not emit fumes. Occasional fumes from de-ashing and re-fuelling may occur but persistent fume emission must not be tolerated.




If fume emission does persist, then the following immediate action should be taken:—
a) Open doors and windows to ventilate room.
b) Let the fire out or remove lit fuel from cooker.
c) Check for flue or chimney blockage, and clean if required.
d) Do not attempt to relight fire until cause of fume has been identified, and if necessary, seek professional advice.

28. Spares List		
Part Number	Description	No. Reqd.
QWX	Boiler Thermostat	1
1/16182 T	Bottomgrate bars top	6
1/16182 B	Bottomgrate bars bottom	5
3/16272	Oven side firebricks	2
4/16273	Firebox side top firebrick	1
3/16271	Front firebrick	1
3/16274	Removable boiler face rear firebrick	1
3/16275	Removable boiler face side firebrick	2
3/18172	Grate Baffle	1

Replacement parts if required are always available ex-works. Write to us should any difficulty be encountered in obtaining them from your usual supplier

With Aga's policy of continuous product improvement, the Company reserves the right to change specifications and make modifications to the appliance described and illustrated at any time.





ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R2064	NAME PLATE C/W FIXING CLIPS	RS9M35605COMP
2	R2050	THERMOSTAT BEZEL C/W FIXING SCREWS	RS9M22324COMP
3	R2476	THERMOSTAT CONTROL KNOB C/W "D" CLIP	RS9M34056COMP
4	R1786	HOB FILLER ACCESS PLATE	RS5E3-15918
5	A1651	HINGE SPINDLE MOD.74 & RAY TWIN INS.COVERS	AS4M42886
6	R2343	HINGE - INSULATING COVER - CHROME PLATED - SPINDLE	RS4M31963
7	R2691	HINGE COVER GASKET	RS4M30765
8	R1992	INSULATING COVER COMP - ENAMELLED - SPINDLE TYPE	RS9E91265
8	R2426	INSULATING COVER COMP - ENAMELLED - GRUB TYPE	RS9E91265COMP
9	R2055	SET OF 4 CIRCLIPS	RS9M26203SET4
10	R1711	BRACKET FOR INSULATING COVER HANDLE	RS4M23090
11	R1076	DOME WASHER FOR COIL HANDLE	KWSR27740
12	R2176	COIL HANDLE (CHROME PLATED)	RG4M310136
13	R1614	INSULATING COVER LINING PLATE	RS2E91270
14	R1020	SEALDOM - MARSEAL	JMAR20555
14	R1034	THERMOSEAL ROPE FOR TWIN INSULATING COVER	JRPS20466
15	R1842	HOTPLATE CUP	RS5M27
16	R1593	HOTPLATE C/W CUP	RS1M0-16187-27
17	R1038	NO.4 THERMOSEAL ROPE FOR HOTPLATE	JTHR20389X1.6M
19	R1920	HOB-RIBBED-C/W INS COVERS (UP TO S/NO.R198716)	RS9E0-16192CMTC
19	R1921	HOB-RIBBED-PREP FOR COVERS (UP TO S/NO.R198716)	RS9E0-16192COM
19	R1925	HOB C/W INS.COVERS-NEW TYPE-(AFTER S/NO.R198716)	RS9E0-18032CMTC
19	R2427	INSULATING COVER COMP - CHROME - SPINDLE TYPE	RS9M91265COMP
19	R2124	INSULATING COVER COMP - CHROME - SPINDLE TYPE	RS9M91265COMP
20	R1723	CHROME PLATED HANDRAIL	RS4M31644
22	A1744	HANDRAIL BRACKET C/W BOLTS & NUTS-MOD 74-	AS9M3-9124COMP
23	R1713	CHROME CAP SCREW FOR HOB	RS4M24420
24	R1066	CORNER STAY NUT 3/8"	KNUT53090
25	R1749	CORNER STAY ROD SHORT	RS4M41109
27	R1787	FLUE CHAMBER C.I. DAMPER BLADE - RIBBED	RS5E3-16791
27	R1789	FLUE CHAMBER DAMPER BLADE - NEW TYPE	RS5E3-17836
28	R1641	FLUE CHAMBER BLANKING PLATE	RS4E38977
29	R1642	FLUE CHAMBER SOCKET	RS4E42644
30	R2244	FLUE CHAMBER FIXING BRACKET - RH/LH	RS2M91190
31	R2123	FLUE CHAMBER BLANKING PLATE STRAP	RS9M91255COMP
33	R1991	FLUE CHAMBER COMP.-RIBBED-(UP TO S/NO.R198716)	RS9E91250COM
33	R1958	FLUE CHAMBER COMP.-NEW TYPE-(AFTER S/NO.R198716)	RS9E3-13344
37	R1785	FLUE CHAMBER DOOR	RS5E3-13344
42	R1743	FLUE CHAMBER DOOR LEVER	RS4M36072
45	R1619	THERMOSTAT DRIVE LOCATING BRACKET	RS2V22865
47	R1719	THERMOSTAT DRIVE SHAFT	RS4M28388
48	R2125	THERMOSTAT FLAP SQUARE C/W PAD	RS9M91287COMP
49	R1009	SEAL PAD FOR INLET FLAP 4/17619	JAPR27949
50	R1768	THERMOSTAT ONLY RAY 12/17	RS4T46670
50	R2132	THERMOSTAT C/W FIXING BOLTS, NUTS & WASHERS	RS9T46670COMP
52	R1634	BACK PLATE	RS2V91305
53	R2070	PAIR COLLARS FOR BOILER CONNECTIONS	RS9M39PR
54	R1636	LH SIDE PLATE	RS2V91315
55	R2128	PR 1" STEEL BOILER CONNECTIONS - SIDE	RS9M91505PR-ST
56	R2434	BOILER - N/T AFTER S.NO.R198716	RS1W301064
56	R2937	SUPREME BOILER - OLD TYPE BEFORE SERIAL NO R198716	RS9W22690
58	R2414	BOILER CLEANING DOOR FIXING BRACKET	RO2M93060
60	R3031	BOILER CLEANING COVER	RO2V340412
61	R1094	BOILER CLEANING DOOR LOCATING BRACKET	RG2M91244
65	R2669	FIREBOX SIDE PLATE	RS5M301079
66	R1859	FIREBRICK RETAINING BRACKET	RS5M3-16288
67	R2688	CENTRE ANGLE	RG2M90371
68	R2690	BRACKET - BASEPLATE	RG4M22963
70	R1706	CHROME IRON BOTTOMGRATE BAR TOP-SINGLE	RS4M22093
71	R1707	CHROME IRON BOTTOMGRATE BAR BTM-SINGLE-	RS4M22094
72	R1709	BOTTOMGRATE REAR SPACER CHROME IRON	RS4M22098
73	R1857	ROCKER BAR	RS5M3-16177
75	R1896	RIDDLING CONNECTOR	RS5M4-16203
76	R1895	RIDDLING BUSH	RS5M4-16201
77	R1756	RIDDLING ROD	RS4M41156
78	H1192	RIDDLING ROD KNOB PLASTIC 5/16 RAY 80.C30.P76.101.	HS4M34012

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
79	R2479	BASE PLATE	RG5M313072
81	R1805	HOB PROTECTION PLATE N/T	RS5M0-17822
83	R2572	OVEN TOP R.H.SIDE FLUE PLATE	RG5M3-16199
84	R1804	OVEN TOP PLATE	RS5M0-16198
85	R2858	FLUE ASSEMBLY TOP OVEN	RS2V91285
86	R1812	OVEN TOP BACK FLUE PLATE O.F.	RS5M1-16193
88	R1913	OVEN BACKPLATE	RS5O5-RH
89	R1916	OVEN SIDE -REMOVABLE- R.H.O.	RS5O8-RH
91	R2953	BRACKET - FIREBOX SIDE FIXING	RS5M301092
92	R2597	TOP OVEN BOTTOM PLATE 4-RH	RS5O300015
93	R1915	OVEN SIDE -FIXED- R.H.O.	RS5O7-RH
95	R1761	OVEN STAY ROD	RS4M44111
96	R2701	VENT PIPE - WARMING OVEN	RS2M91495
98	R1601	WARMING OVEN ASSEMBLY	RS1V91100
102	R2080	DAMPER ROD C/W HANDLE & BOILER & COOKER BLADES	RS9M41154COMP
110	R1732	DAMPER HANDLE	RS4M34054
112	R1810	SECONDARY AIR SEALING PLATE	RS5M1-16190
114	R1893	SECONDARY AIR SHUT OFF SLIDE	RS5M4-13705
115	R1708	SECONDARY AIR SEALING PLATE FOOT	RS4M22095
116	R1021	SHIELD HEAT TOP -BARLAN- 4MM	JPAD30770
117	R1811	ASHPIT DOOR FRAME	RS5M1-16191
118	R2188	CLINKER DOOR	RS4M22096
118	R2049	CLINKER DOOR C/W HANDLE	RS9M22096COMP
119	R1615	CLINKER DOOR HANDLE	RS2M91275
120	R2382	GLASS FIBRE ROPE 7MM X 2700MM LONG	JTHR20390X2700
121	R2082	SET PACKING C/W SCRWS FOR F/DOOR	RS9M41776COMP
122	R2072	FIREDOOR PROT PLATE COMP	RS9M4-16202COMP
123	R1031	FIREDOOR HEAT SHIELD	JPAD41776
125	R1930	FIREDOOR COMPLETE	RS9E1-16079
126	R1616	ASHPIT DOOR BAFFLE PLATE	RS2M91280
127	R2057	ASHPIT DOOR BAFFLE PLATE DIST.PIECES C/W FITTINGS	RS9M28060COMP
128	R1931	ASHPIT DOOR COMPLETE	RS9E1-16174
129	A1950	OVEN DOOR NYLON WASHER 5/8"X 5/16"X 1/32"	KWSR53500
130	R1074	SPINWHEEL ALTHREAD	KSTD52107
132	R2084	SPIN WHEEL C.P.C/W FIXINGS	RS9M43460COMP
134	A1950	OVEN DOOR NYLON WASHER 5/8"X 5/16"X 1/32"	KWSR53500
135	R1089	WARMING OVEN DOOR LINING	RG2M310115
136	R2061	DOOR HANDLE -HORIZ- C/W SCREWS	RS9M31530COMP
137	R2432	OVEN THERMODIAL BI-METAL ROUND	RS4T301075
138	R1147	GASKET THERMODIAL PERM AF 2000	RG4M30412
140	R1972	OVEN DOOR -NO THERMODIAL	RS9E519N-T
141	R1705	SLAGWOOL MATTING FOR OVEN DOOR	RS4M20490
142	R2931	OVEN DOOR LINING	RO2M320198
143	R1734	OVEN DOOR CATCH/FIREDOOR STUD	RS4M34120
145	R1618	OVEN SHEET IRON SHELF ALL MODELS	RS2O90010
146	R2573	OVEN GRID SHELF ALL MODELS	RS4M300070
147	R1004	MEAT TRAY	EMTY47744
148	R2248	BARLAN PAD 100 X 320 X 4MM	JPAD37336
149	R1021	SHIELD HEAT TOP	JPAD30770
150	R1923	FRONT C/W DOORS	RS9E0-16197
151	R1635	RH SIDE PLATE - OVEN SIDE SUPREME	RS2V91310
152	R1760	CORNER STAY ROD ONLY	RS4M44080
152	R2088	CORNER STAY RODS & NUTS SET OF 4	RS9M44080SET4
153	R1716	ASHPIT F'DR CATCH P/CESS RHAP.RYL.SF MF	RS4M26000
154	R1860	BOTTOMGRATE BAFFLE - WOODBURNING ONLY	RS5M3-18172

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R1658	REMOVABLE SIDE BRICK - PT NO.3/16275	RS4F3-16275
1	R1658	REMOVABLE SIDE BRICK - PT NO.3/16275	RS4F3-16275
2	R1657	REAR BRICK	RS4F3-16274
3	R1656	OVEN SIDE BRICK - PT NO.3/16272	RS4F3-16272
3	R1656	OVEN SIDE BRICK - PT NO.3/16272	RS4F3-16272
4	R1678	FIREBOX SIDE TOP BRICK	RS4F4-16273
5	R1655	FRONT BRICK	RS4F3-16271