



# MASTERCHEF DELUXE 90 DUAL FUEL



## USER GUIDE & INSTALLATION INSTRUCTIONS

U111083-02



Each piece in the AGA Cookshop collection has been designed for optimum performance, to get the best results from your cooker.

Developed by experts, our range of exclusive and essential cookware is designed for quality, performance and durability.

AGA Cookshop has everything you need to get the most from your cooker, including stainless steel cookware, lightweight non-stick cast aluminium cookware, innovative and practical textiles, and a wide range of traditional and contemporary kettles. There are many items in the range suitable for all heat sources ceramic, halogen and induction hobs too.

[agacookshop.co.uk](http://agacookshop.co.uk)

## CHOCOLATE SHORTBREADS

Makes 20 – 24

### Ingredients

- 175g (6 oz) butter
- 50g (2 oz) caster sugar
- 200g (7 oz) plain flour
- 25g (1 oz) cornflour

### To finish:

- 50g (1¾ oz) melted plain chocolate
- 50g (1¾ oz) melted white chocolate

### Method

1. Cream the butter and sugar together and stir in the flour and cornflour. Use your hand to pull the dough together into a ball.
2. Roll out the dough and cut into ovals or circles. Place on two baking sheets.
3. Bake at 180°C (350°F), fan oven 160°C, Gas Mark 4 for about 20 minutes until a light golden colour.
4. Remove the shortbread from the oven, allow to cool for 5 minutes then remove to a cooling rack. Cool for 10 minutes.
5. Drizzle the chocolate over the cooled shortbread or pipe in a zigzag fashion, as shown. Let the chocolate set then serve alone or to complement a dessert.



## TANDOORI CHICKEN WITH MINT YOGURT

Serves 4

### Ingredients

- 2 packets mini chicken fillets
- Juice of ½ lemon
- ½ tsp salt
- ¼ tsp cardamom seeds
- 2 tsp cumin seeds
- 1 tsp fennel seeds
- 3 tsp fresh ginger, grated
- 2 cloves of garlic, crushed
- 1 tsp chilli powder
- 200g tub of natural yogurt

### Mint yogurt:

- 200g Greek yogurt
- 1 tbsp fresh mint, chopped
- ¼ tsp salt
- 1 tsp sugar

### Method

1. Place the chicken fillets in a basin, squeeze over the lemon juice and sprinkle with salt. Mix well together.
2. Heat a small frying pan on the hob and dry fry the cardamom, cumin and fennel seeds for 2 minutes until the seeds begin to colour. Transfer to a large bowl and add the ginger, garlic, chilli powder and yogurt, mix together. Stir in the chicken fillets and chill overnight.
3. Pre-heat the grill for 5 minutes. Lightly oil the grill rack and add the chicken fillets. Grill for about 15-20 minutes, until cooked, turning once. Serve with the mint yogurt.

### To make the mint yogurt:

Mix the yogurt, mint, salt and sugar together and serve to accompany the Tandoori Chicken.

# Contents

|                                       |           |                                               |           |
|---------------------------------------|-----------|-----------------------------------------------|-----------|
| <b>1. Before You Start...</b>         | <b>1</b>  | <b>9. Troubleshooting</b>                     | <b>24</b> |
| Personal Safety                       | 1         | <b>10. Installation</b>                       | <b>26</b> |
| Electrical Connection Safety          | 1         | Dear Installer                                | 26        |
| If You Smell Gas                      | 3         | Safety Requirements and Regulations           | 26        |
| Peculiar Smells                       | 3         | Provision of Ventilation                      | 26        |
| Cooling Fan                           | 3         | Location of Cooker                            | 27        |
| Ventilation                           | 3         | Conversion                                    | 27        |
| Maintenance                           | 3         | Positioning the Cooker                        | 28        |
| Grill/Glide-out Grill™ Care           | 6         | Moving the Cooker                             | 28        |
| Cooker Care                           | 6         | Fitting the Stability Bracket or Chain        | 29        |
| Cleaning                              | 6         | Repositioning the Cooker Following Connection | 29        |
| <b>2. Cooker Overview</b>             | <b>7</b>  | Conversion to Another Gas                     | 30        |
| Hotplate Burners                      | 7         | Fitting the Handles                           | 30        |
| The Wok Cradle ( <i>optional</i> )    | 8         | Levelling                                     | 30        |
| The Glide-out Grill                   | 9         | Gas Connection                                | 31        |
| The Ovens                             | 10        | Electrical Connection                         | 32        |
| Accessories                           | 13        | Final Checks                                  | 33        |
| Oven Lights                           | 13        | Final Fitting                                 | 33        |
| <b>3. Using the Glide-out Grill™</b>  | <b>14</b> | Customer Care                                 | 33        |
| <b>4. Using the Probe</b>             | <b>15</b> | <b>11. Conversion to LP Gas</b>               | <b>34</b> |
| <b>5. 3 button clock</b>              | <b>16</b> | Injectors                                     | 34        |
| <b>6. Cooking tips</b>                | <b>18</b> | Bypass Screw Adjustment                       | 35        |
| <b>7. Cooking Table</b>               | <b>19</b> | Pressure Testing                              | 35        |
| <b>8. Cleaning Your Cooker</b>        | <b>20</b> | <b>12. Circuit Diagram</b>                    | <b>36</b> |
| Hotplate Burners                      | 20        | <b>13. Technical Data</b>                     | <b>37</b> |
| The Griddle ( <i>optional extra</i> ) | 20        |                                               |           |
| Glide-out Grill                       | 21        |                                               |           |
| Control Panel and Doors               | 21        |                                               |           |
| Ovens                                 | 22        |                                               |           |
| Cleaning Table                        | 23        |                                               |           |



# 1. Before You Start...

---

Your cooker should give you many years of trouble-free cooking if installed and operated correctly. It is important that you read this section before you start.

## Personal Safety

This appliance is for cooking purposes only. It must not be used for other purposes, for example heating a room. Using it for any other purpose could invalidate any warranty or liability claim. Besides invalidating claims this wastes fuel and may overheat the control knobs.

This appliance is for use in Great Britain and the Republic of Ireland. It is a Cat II<sub>2H3+</sub> cooker and is set for G20 at 20 mbar. (A conversion kit for LPG is available for the cooker).


- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **WARNING:** Children **less** than 8 years of age should be kept away unless continuously supervised. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The cooker should not be placed on a base.
- This appliance is designed for domestic cooking only. Use for any other purpose could invalidate any warranty or liability claim.
- Before operating the ovens please refer to the oven shelf installation, in the Accessories section.
- **WARNING:** The appliance and its accessible parts become hot during use and will retain heat even after you have stopped cooking. Care should be taken to avoid touching heating elements. Children less than 8 years of age shall be kept away unless continuously supervised.
- **CAUTION:** A long term cooking process has to be supervised from time to time. A short term cooking process has to be supervised continuously.
- At the risk of fire **DO NOT** store items on the cooking surfaces.
- To avoid overheating, **DO NOT** install the cooker behind a decorative door.
- **WARNING:** Accessible parts will become hot during use and will retain heat even after you have stopped cooking. Keep babies and children away from the cooker and never wear loose-fitting or hanging clothes when using the appliance.
- **DO NOT** use a steam cleaner on your cooker.
- Always keep combustible materials, e.g. curtains, and flammable liquids a safe distance away from the cooker.
- **DO NOT** spray aerosols in the vicinity of the cooker while it is on.

## Electrical Connection Safety


**A Gas Safe registered engineer should service the cooker and only approved spare parts should be used.**

**The electrical installation must be installed in accordance with all relevant British Standards/Codes of Practice, BS 7671. Or with the relevant national and local regulations and with the local gas and electricity supply companies' requirements.**

**Fig. 1.1**



**Fig. 1.2**



Otherwise, all installations must be in accordance with the relevant instructions in this booklet.

**⚠ WARNING: THE APPLIANCE MUST BE EARTHED.**

**Note:** The cooker must be connected to the correct electrical supply as stated on the voltage label on the cooker, through a suitable cooker control unit incorporating a double-pole switch, having a contact separation of at least 3 mm in all poles.

**⚠ The cooker MUST NOT be connected to an ordinary domestic power point.**

Access to the mains terminal is gained by removing the electrical terminal cover box on the back panel. Connect the mains cable to the correct terminals for your electrical supply type (**Fig. 1.1** and **Fig. 1.2**). Check that the links are correctly fitted and that the terminal screws are tight. Secure the mains cable using the cable clamp.

Minimum temperature rating T105.

Read the instructions before installing or using this appliance.

## Gas Connection Safety

- This cooker is a Class 2 Subclass 1 appliance.
- This appliance can be converted for use on another gas.
- Before installation, make sure that the cooker is suitable for your gas type and supply voltage. See the data badge.
- DO NOT use reconditioned or unauthorised gas controls.
- Disconnect from the electricity and gas supply before servicing.
- When servicing or replacing gas-carrying components disconnect from the gas supply before starting operation. Check the appliance is gas sound after completion.

- Make sure that the gas supply is turned on and that the cooker is wired in and switched on.
- In your own interest and that of safety, it is law that all gas appliances be installed by a qualified person(s).
- An appliance for use on LPG must not be installed in a room or internal space below ground level, e.g. in a basement.

**This cooker must be installed in accordance with:**

- British Standards/Codes of Practice, BS 5440 Part 2
- Natural Gas: BS 6172 and BS 6891
- LP Gas: BS 5482-1 (when the installation is in a permanent dwelling)
- Gas Safety (Installation and Use) regulations
- Relevant Building/IET regulations

**If You Smell Gas**

- **DO NOT** turn electric switches on or off
- **DO NOT** smoke
- **DO NOT** use naked flames
- Turn off the gas at the meter or cylinder
- Open doors and windows to get rid of the gas
- Keep people away from the area affected
- Call your gas supplier
- **If you are using Natural Gas in the UK, ring the National Grid on: 0800 111 999**

**Peculiar Smells**

When you first use your cooker it may give off an odour. This should stop after use.

Before using for the first time, make sure that all packing materials have been removed and then, to dispel manufacturing odours, turn the ovens to 200 °C and run for at least an hour.

Before using the grill for the first time you should also turn on the grill and run for 30 minutes with the grill pan in position, pushed fully back and the grill door open.

Make sure the room is well ventilated to the outside air (see 'Ventilation' below). People with respiratory or allergy problems should vacate the area for this brief period.

**Cooling Fan**

This appliance may have a cooling fan. When the grill or ovens are in operation the fan will run to cool the fascia and control knobs.

**Ventilation**

The use of a cooking appliance results in the production of heat and moisture in the room in which it is installed. Therefore, make sure that the kitchen is well ventilated: keep natural ventilation holes open or install a powered cookerhood that vents outside. If you have several hotplates/burners on, or use the cooker for a long time, open a window or turn on an extractor fan

**Maintenance**

- It is recommended that this appliance is serviced annually.
- **WARNING:** Before replacing the bulb, turn off the power supply and make sure that the oven is cool.
- **DO NOT** use cooking vessels on the hotplate that overlap the edges.
- Unless specified otherwise in this guide, always allow the cooker to cool and then switch it off at the mains before cleaning or carrying out any maintenance work.
- **DO NOT** use the control knobs to manoeuvre the cooker.

- **NEVER** operate the cooker with wet hands.
- **DO NOT** use a towel or other bulky cloth in place of a glove – it might catch fire if brought into contact with a hot surface.
- **DO NOT** use hotplate protectors, foil or hotplate covers of any description. These may affect the safe use of your hotplate burners and are potentially hazardous to health.
- **NEVER** heat unopened food containers. Pressure build up may make the containers burst and cause injury.
- **WARNING:** Use only hob guards designed by the manufacturer of the cooking appliance or indicated by the manufacturer of the appliance in the instructions for use as suitable or hob guards incorporated in the appliance. The use of inappropriate guards can cause accidents.
- **DO NOT** use unstable saucepans. Always make sure that you position the handles away from the edge of the hotplate.
- **NEVER** leave the hotplate unattended at high heat settings. Pans boiling over can cause smoking, and greasy spills may catch on fire. Use a deep fat thermometer whenever possible to prevent fat overheating beyond the smoking point.

**⚠ WARNING: Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.**

- **NEVER** try to extinguish a fire with water, but switch off the appliance and then cover the flame e.g. with a lid or a fire blanket.
- **NEVER** leave a chip pan unattended. Always heat fat slowly, and watch as it heats. Deep fry pans should be only one third full of fat.
- **WARNING: Danger of fire: do not store items on the cooking surfaces.**
- **NEVER** try to move a pan of hot fat,


especially a deep fat fryer. Wait until the fat is cool. Filling the pan too full of fat can cause spill over when food is added. If you use a combination of oils or fats in frying, stir them together before heating, or as the fats melt.

- Foods for frying should be as dry as possible. Frost on frozen foods or moisture on fresh foods can cause hot fat to bubble up and over the sides of the pan. Carefully watch for spills or overheating of foods when frying at high or medium high temperatures.
- **DO NOT** use the top of the flue (the slot along the back of the cooker) for warming plates, dishes, drying tea towels or softening butter.
- **DO NOT** use water on grease fires and never pick up a flaming pan. Turn the controls off and then smother a flaming pan on a surface unit by covering the pan completely with a well fitting lid or baking tray. If available, use a multi-purpose dry chemical or foam-type fire extinguisher.
- **DO NOT** modify this appliance. This appliance is not intended to be operated by means of external timer or separated remote-control system.
- If flammable materials are stored in the drawer, oven(s) or grill(s) it may explode and result in fire or property damage.


## Oven Care

- When the oven is not in use and before attempting to clean the cooker always be certain that the control knobs are in the **OFF** position.
- Use oven gloves to protect your hand from potential burns.
- Cooking high moisture content foods can create a 'steam burst' when the oven door is opened (**Fig. 1.3**). When opening the oven, stand well back and allow any steam to disperse.

- The inside door face is constructed with toughened safety glass. Take care **NOT** to scratch the surface when cleaning the glass panel.
- Accidental damage may cause the door glass panel to fracture.
- Keep oven vent ducts unobstructed.
- **DO NOT** use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
- Make sure the shelves are pushed firmly to the back of the oven. **DO NOT** close the door against the oven shelves.
- **DO NOT** use aluminium foil to cover shelves, linings or the oven roof.
- When the oven is on, **DO NOT** leave the oven door open for longer than necessary, otherwise the control knobs may become very hot.
- **DO NOT** use the timed oven if the adjoining oven is already warm.
- **DO NOT** place warm food in the oven to be timed.
- **DO NOT** use a timed oven that is already warm.
- Use dry oven gloves when applicable – using damp gloves might result in steam burns when you touch a hot surface.



**Fig. 1.3**



**Fig. 1.4**

## Oven Shelves

To fit the glide-out shelf, hook the front of the shelf onto the runners as shown (**Fig. 1.4**). The rear of the shelf should rest on the runners, in front of the rear stop (**Fig. 1.4**).

Standard oven shelves can be fitted by lining up the shelf with a groove in the oven ladders. Push the shelf back until the ends hit the shelf stop. Lift the front so the shelf clears the stops, then lower the front so the shelf is level and push it fully back.

## Grill/Glide-out Grill™ Care

**⚠ WARNING: Unattended cooking under the grill can be dangerous and may result in fire.**

- When using the grill, make sure that the grill pan is in position and pushed fully in, otherwise the control knobs may become very hot.
- **DO NOT** leave the grill on for more than a few moments without the grill pan underneath it, otherwise the knobs may become hot.
- **NEVER** close the grill door when the grill is on.
- Accessible parts may be hot when the grill is in use. Young children should be kept away

## Cooker Care

As steam can condense to water droplets on the cool outer trim of the oven, it may be necessary during cooking to wipe away any moisture with a soft cloth. This will also help to prevent soiling and discolouration of the oven exterior by cooking vapours.

## Cleaning

- Isolate the electricity supply before carrying out any thorough cleaning. Allow the cooker to cool.
- In the interests of hygiene and safety, the cooker should be kept clean at all times as a build up in fats and other food stuff could result in a fire.
- Clean only the parts listed in this guide.
- Clean with caution. If a wet sponge or cloth is used to wipe spills on a hot surface, be careful to avoid steam burns. Some cleaners can produce noxious fumes if applied to a hot surface.
- **NEVER** use paint solvents, washing soda, caustic cleaners, biological powders,

bleach, chlorine based bleach cleaners, coarse abrasives or salt.

- **DO NOT** mix different cleaning products – they may react together with hazardous results.
- All parts of the cooker can be cleaned with hot soapy water.
- Take care that no water seeps into the appliance.
- Before you remove any of the grill parts for cleaning, make sure that they are cool or use oven gloves.
- **DO NOT** use any abrasive substances on the grill and grill parts.
- **DO NOT** put the side runners in a dishwasher.
- **DO NOT** put the burner heads in a dishwasher.
- **NEVER** use caustic or abrasive cleaners as these will damage the surface.
- **DO NOT** use steel wool, oven cleaning pads or any other materials that will scratch the surface.
- **NEVER** store flammable materials in the drawer. This includes paper, plastic and cloth items, such as cookbooks, plastic ware and towels, as well as flammable liquids.
- **DO NOT** store explosives, such as aerosol cans, on or near the appliance.
- **DO NOT** use steel wool, oven cleaning pads, or any other materials that will scratch the surface.
- **DO NOT** attempt to disassemble or clean around any burner while another burner is on, otherwise an electric shock could result.

## 2. Cooker Overview



The 110 dual fuel cooker (**Fig. 2.1**) has the following features:

- A.** 5 hotplate burners
- B.** A control panel
- C.** A glide-out grill
- D.** A multi-function oven
- E.** A fan oven

### Hotplate Burners

The drawing by each of the central knobs indicates which burner that knob controls.

Each burner has a Flame Supervision Device (FSD) that prevents the flow of gas if the flame goes out.

**When a hotplate control knob is pressed in, sparks will be made at every burner – this is normal. Do not attempt to disassemble or clean around any burner while another burner is on, otherwise an electric shock could result.**

To light a burner, push in and turn the associated control knob to the high position, as indicated by the large flame symbol (H), (**Fig. 2.2**).

The igniter should spark and light the gas. Keep holding the knob pressed in to let the gas through to the burner for about ten seconds.





Fig. 2.3



If, when you let go of the control knob, the burner goes out, then the FSD has not been bypassed. Turn the control knob to the OFF position and wait for one minute before you try again, this time making sure to hold in the control knob for slightly longer.

Adjust the flame height to suit by turning the knob counter-clockwise (**Fig. 2.3**). On this cooker the low position is beyond high, **NOT** between high and off.

**If a burner flame goes out, turn off the control knob and leave it for one minute before relighting it.**

Make sure that the flames are under the pans. Using a lid will help the contents boil more quickly (**Fig. 2.4**).

Fig. 2.4




Fig. 2.5




Fig. 2.6





Fig. 2.7



Large pans should be spaced well apart.

Pans and kettles with concave bases or down-turned base rims should not be used (**Fig. 2.5**).

Simmering aids, such as asbestos or mesh mats, are **NOT** recommended (**Fig. 2.6**). They will reduce burner performance and could damage the pan supports.

You should also avoid using unstable and misshapen pans that may tilt easily, and pans with a very small base diameter, e.g. milk pans, single egg poachers (**Fig. 2.7**).

The minimum recommended pan diameter is 120 mm. The maximum allowable pan base diameter is 260 mm.

**DO NOT** use cooking vessels on the hotplate that overlap the edges.

### The Wok Cradle (optional)

The wok cradle (**Fig. 2.8**) is designed to fit the centre burner. It will not fit any of the other burner pan supports.

It should be located so that the cut-outs in the cradle sit directly on the projecting burner supports (**Fig. 2.9**).

Woks vary very widely in size and shape. It is important that the wok is securely held: if the wok is too big or too small the cradle will not support it properly.

For the wok to heat properly it must be close to the burner. For this reason we recommend that you do not use the wok cradle with a flat bottomed wok.

When you fit the cradle, check that it is properly located on the pan support fingers. Make sure that it is stable and that the wok is sitting level in the cradle.

**⚠ The wok cradle will get very hot in use – allow plenty of time for it to cool before you pick it up.**

Fig. 2.8





Fig. 2.9



## The Glide-out Grill

**⚠ DO NOT leave the grill on for more than a few moments without the grill pan underneath it, otherwise the knobs may become hot.**

**⚠ When the trivet has been removed from the grill pan, please ensure that the grill pan and cradle are fully returned into the grill chamber. The grill door MUST remain open.**

1. For best results, slide the carriage back into the grill chamber and preheat the appropriate part(s) of the grill for two minutes. The grill trivet can be removed and the food placed on it while you are waiting for the grill to preheat.
2. Do not leave the grill oven door open for more than a few moments, otherwise the knobs may become hot.
3. Preheat the grill chamber prior to placing the food on the trivet. Once the trivet is placed back into the grill pan, place the grill pan back into the grill carriage. Slide the carriage back into the grill chamber.

**⚠ Accessible parts may be hot when the grill is in use. Young children should be kept away.**

| <b>Function</b>          | <b>Use</b>                                                                    |
|--------------------------|-------------------------------------------------------------------------------|
| <b>Rapid response</b>    | To preheat the oven faster than normal.                                       |
| <b>Defrost</b>           | To thaw small items in the oven without heat                                  |
| <b>Fan oven</b>          | A full cooking function, even heat throughout, great for baking               |
| <b>Fanned grilling</b>   | Grilling meat and fish with the door closed                                   |
| <b>Fan assisted</b>      | A full cooking function good for roasting and baking                          |
| <b>Conventional oven</b> | A full cooking function for roasting and baking in the lower half of the oven |
| <b>Browning element</b>  | To brown and crisp cheese topped dishes                                       |
| <b>Base heat</b>         | To crisp up the bases of quiche, pizza or pastry                              |

**Table 2-1**

## The Ovens

**The clock must be set to the time of day before the left-hand oven will work. See the following section on 'The Clock' for instructions on setting the time of day.**

*References to 'left-hand' and 'right-hand' ovens apply as viewed from the front of the appliance.*

The left-hand oven is a multi-function oven, while the right-hand oven is a tall fan oven.

### The Multi-function Oven

As well as the oven fan and fan element, multi-function ovens are fitted with two extra heating elements, one visible in the top of the oven and the second under the oven base. Take care to avoid touching the top element and element deflector when placing or removing items from the ovens.

The multi-function oven has 3 main cooking functions: **fan**, **fan assisted** and **conventional cooking**. These functions should be used to complete most of your cooking.

The **browning element** and **base heat** can be used in the latter part of the cooking process to fine tune the results to your particular requirements.

Use **fanned grilling** for all your grilling needs and **defrost** to safely thaw small items of frozen food.

**Table 2-1** gives a summary of the multi-function modes.

The multi-function ovens have many varied uses. We suggest you keep a careful eye on your cooking until you are familiar with each function. Remember – not all functions will be suitable for all food types.

### Multi-function Oven Functions

#### Rapid Response



The Rapid Response setting enables you to preheat the oven faster than normal. It uses the fan oven element with additional heat from one of the elements in the top of the oven. Fan ovens heat up quickly; but the Rapid Response feature speeds this process up enabling you to start cooking sooner.

To use the Rapid Response feature, turn the function control knob to **R** and set the temperature required. The light on the control panel next to the function control will come on.

When the required temperature is reached the top element will switch off and the light will go out.

The oven temperature is then maintained by the fan oven element and fan.

Should you choose to place food into the cold oven prior to cooking while using the Rapid Response function, make sure that cakes, etc. are not positioned too near the top of the oven.

## Fan Oven



This function operates the fan and the heating element around it. An even heat is produced throughout the oven, allowing you to cook large amounts quickly.

Fan oven cooking is particularly suitable for baking on several shelves at one time and is a good 'all-round' function. It may be necessary to reduce the temperature by approximately 10°C for recipes previously cooked in a conventional oven.

If you wish to preheat the oven, wait until the indicator light has gone out before inserting the food.

## Fanned Grilling



This function operates the fan whilst the top element is on. It produces a more even, less fierce heat than a conventional grill. For best results, place the food to be grilled, on a grid over a roasting tin, which should be smaller than a conventional grill pan. This allows greater air circulation. Thick pieces of meat or fish are ideal for grilling in this way, as the circulated air reduces the fierceness of the heat from the grill.

The oven door should be kept closed while grilling is in progress, so saving energy. You will also find that the food needs to be watched and turned less than for normal grilling. Preheat this function before cooking.

For best results we recommend that the grill pan is not located on the uppermost shelf.

## Fan Assisted Oven



This function operates the fan, circulating air heated by the elements at the top and the base of the oven.

The combination of fan and conventional cooking (top and base heat) makes this function ideal for cooking large items that need thorough cooking, such as a large meat roast.

It is also possible to bake on two shelves at one time, although they will need to be swapped over during the cooking time, as the heat at the top of the oven is greater than at the base, when using this function.

This is a fast intensive form of cooking; keep an eye on the food cooking until you have become accustomed to this function.

## Conventional Oven (Top and Base Heat)



This function combines the heat from the top and base elements. It is particularly suitable for roasting and baking pastry, cakes and biscuits.

Food cooked on the top shelf will brown and crisp faster than on the lower shelf, because the heat is greater at the top of the oven than at the base, as in 'Fan Assisted Oven' function. Similar items being cooked will need to be swapped around for even cooking. This means that foods requiring different temperatures can be cooked together, using the cooler zone in the lower half of the oven and hotter area to the top.

The exposed top element may cook some foods too quickly, so we recommend that the food be positioned in the lower half of the oven to cook. The oven temperature may also need to be lowered.

## Browning Element



This function uses the element in the top of the oven only. It is a useful function for the browning or finishing of pasta dishes, vegetables in sauce, shepherds pie and lasagne, the item to be browned being already hot before switching to the top element.

## Base Heat



This function uses the base element only. It will crisp up your pizza or quiche base or finish off cooking the base of a pastry case on a lower shelf. It is also a gentle heat, good for slow cooking of casseroles in the middle of the oven or for plate warming.

The Browning and Base Heat functions are useful additions to your oven, giving you flexibility to finish off items to perfection.

## Defrost



This function operates the fan to circulate cold air only. Make sure the temperature control is at 0°C and that no heat is applied. This enables small items such as desserts, cream cakes and pieces of meat, fish and poultry to be defrosted.

Defrosting in this way speeds up the process and protects the food from flies. Pieces of meat, fish and poultry should be placed on a shelf, over a tray to catch any drips. Be sure to wash the shelf and tray after defrosting.

Defrost with the oven door closed.

Large items, such as whole chickens and joints should not be defrosted in this way. We recommend this be carried out in a refrigerator.

Defrosting should not be carried out in a warm oven or when an adjoining oven is in use or still warm.

Make sure that dairy foods, meat and poultry are completely defrosted before cooking.


## The Fan Oven

The right-hand oven is a fan oven that circulates hot air continuously, which means faster, more even cooking.

The recommended cooking temperatures for a fan oven are generally lower than a conventional oven.

**Note:** Please remember that all cookers vary so temperatures in your new ovens may differ to those in your previous cooker.

**Fig. 2.10**



## Operating the Ovens

### Fan Oven

Turn the oven knob to the desired temperature (**Fig. 2.10**).

The oven indicator light will glow until the oven has reached the temperature selected. It will then cycle on and off during cooking.


### Multi-function Oven

The multi-function oven has two controls: a function selector and a temperature setting knob (**Fig. 2.11**).


Turn the function selector control to a cooking function. Turn the oven temperature knob to the temperature required (**Fig. 2.12**).

The oven heating light will glow until the oven has reached the temperature you selected. It will then cycle on and off during cooking.

**Fig. 2.11**



**Fig. 2.12**



## Accessories

### Oven Shelves

The range is supplied with the following:

- 2 telescopic shelves with runners (**Fig. 2.13**).
- 1 sets of side supports (**Fig. 2.14**).

The oven shelves are retained when pulled forward but can be easily removed and refitted.

#### To fit the telescopic shelf runners

1. With the runner arm in the closed position locate the opening of the upper rear slot onto the side support (**Fig. 2.15**). Do not locate any further than the opening at this point.
2. Lift the front of the runner arm to locate the front slot against the side support (**Fig. 2.15**).
3. Push the runner arm towards the rear of the oven. The catch at the front will lift and drop to secure the runner arm in place (**Fig. 2.15**).

#### To fit a shelf to the telescopic shelf runners

Slide the telescopic runners forward until they stop. Holding the shelf above the runners, tilt the front downward and locate into the front of the runners. Lay the shelf flat. Press on the rear of the shelf to secure in place.

#### To remove a shelf from the telescopic shelf runners

1. Slide the shelf out on the runners. While holding one of the runners securely, carefully lift the rear of the shelf upwards: the shelf will spring clear of the central restraining tab. Repeat for the opposite side of the shelf.
2. Note: To aid the removal of the shelf you can insert a suitable flat tool through the opening in the side of the runners and lever the shelf clear (**Fig. 2.16**).
3. Tilt the front of the shelf downwards and then lift clear of the runners (**Fig. 2.17**).

#### To remove the telescopic shelf runners

1. Firstly, remove the shelf from the runners (see above).
2. Place a finger on the underside of the telescopic runner and lift.
3. Open the catch on top of the runner and pull the runner forward and down to remove.

### Oven Shelves – Right-hand (Tall) Oven

The tall oven is supplied with four flat cooking shelves (**Fig. 2.18**) and a plate warming shelf (**Fig. 2.19**).


When using the tall oven, you can cook on all four shelves at the same time, but make sure that they are well spaced out to allow the hot air to circulate.

### Oven Lights


Press the button to turn the light on (**Fig. 2.20**).

If the oven light fails, turn off the power supply before changing the bulb. See the 'Troubleshooting' section for details on how to change the bulb.


**Fig. 2.13**




**Fig. 2.14**




**Fig. 2.15**




**Fig. 2.16**




**Fig. 2.17**




**Fig. 2.18**



**Fig. 2.19**



**Fig. 2.20**



### 3. Using the Glide-out Grill™

Fig. 3.1






Fig. 3.2




**Four grill height positions  
refer to Fig. 3.5**

Fig. 3.3



**To switch on the right half element**


Fig. 3.4



**To switch on both elements**

#### Four grill height positions

Fig. 3.5



#### Cooking suggestions

1. Nearest to the element – Toast, streaky bacon.
2. Middle high – cheese on toast, welsh rarebit, courgette slices, back bacon.
3. Middle low – fish fillets, vegetable skewers.
4. Furthest from the element – whole fish, thick pork chops, chicken breasts, chicken or beef skewers.

**NOTE:** A short term cooking process has to be supervised continuously.

## 4. Using the Probe

The left-hand oven has a connection port for a meat probe (supplied) (**Fig. 4.1**).

Take care not to damage the port when removing items from the oven.

The probe is used to measure the internal temperature of meat, bread or other cooked foods.

**⚠ IMPORTANT: Ensure that only an AGA approved probe is used (part number : P068958). A non-approved probe will not work.**

**⚠ Do not wash the probe in the dishwasher.**

### Setting the probe temperature to stop the oven

For best results switch the oven on, to pre-heat it. Set the oven to the required cooking temperature.

Insert the probe into the food to be cooked. Plug the probe into the outlet in the oven. Make sure it is pushed all the way in (**Fig. 4.1**).

**⚠ Please take care when inserting or removing the oven probe. Use oven gloves.**

The clock will change to display the current temperature of the probe and the intended stop temperature (**Fig. 4.2**). The stop temperature range can be adjusted from 30°C to 99°C.



To set the stop temperature press the [+] or [-] buttons (**Fig. 4.2**).

The oven will continue cooking until the temperature of the probe has reached the stop temperature. An alarm will sound and the oven will stop cooking.

Press any button to stop the alarm. Remove the cooked item from the oven and the probe.

**⚠ Make sure the oven is turned off and the probe is removed from the outlet in the side of the oven, otherwise it will continue cooking to maintain the probe stop temperature.**


**⚠ If you wish to continue cooking without the probe, make sure the probe is removed from its socket.**




## 5. 3 button clock

**Setting the time** The clock must be set to the time of day before the oven will work

### Step. 1




### Step. 2




## Reset the minute minder

### Step. 1




**Note:** The cook symbol [🔥] remains visible during normal operation.

### Step. 2




## Minute Minder


### Step. 1 Setting the minute minder



### Step. 2




### Step. 3




## To stop the oven at a specific time of day

(main oven only) You have set the required temperature and function mode and you would like the oven to automatically stop.


### Step. 1



### Step. 2




### Step. 3



## To start and stop the oven automatically


(main oven only)

### Step. 1



Press [M] button again until current time is displayed.


### Step. 2



Set the length of time you want the oven to cook for.

Press either [+] or [-] buttons


### Step. 3



Set the length of time you want the oven to cook for.

Press [M] button again until current time is displayed.


### Step. 4



Press either [+] or [-] buttons to set the 'stop time'.

### Step. 5

Current time will be displayed along with the word 'AUTO'. Set the oven to the required cooking temperature and function.



In this example the oven will come on automatically at 10.30am and switch off at 11.00am.

**Step. 6** Alarm will sound when cooking has finished, press any button to stop the alarm.



### REMEMBER

Turn the oven control knob (s) to 0.

If the alarm is not stopped, it will stop automatically after 7 minutes.

## AUTO is showing, but you want to revert to manual cooking


(main oven only)



Press either [+] or [-] buttons


## Changing the frequency of the alarm

### Step. 1



Press [M] button again until current time is displayed.

### Step. 2



Press either [+] or [-] buttons

## 6. Cooking tips

---

### Tips on cooking with the timer

If you want to cook more than one dish, choose dishes that require approximately the same cooking time. However, dishes can be 'slowed down' slightly by using small containers and covering them with aluminium foil, or 'speeded up' slightly by cooking smaller quantities or placing them in larger containers.

Very perishable foods such as pork or fish should be avoided if a long delay period is planned, especially in hot weather.

-  **DO NOT place warm food in the oven to be timed.**
-  **DO NOT use a timed oven that is already warm.**
-  **DO NOT use the timed oven if the adjoining oven is already warm.**

Whole poultry must be thoroughly defrosted before being placed in the oven. Check that meat and poultry are fully cooked before serving.

### General oven tips

The wire shelves should always be pushed firmly to the back of the oven.

Baking trays with food cooking on them should be placed level with the front edge of the oven's wire shelves. Other containers should be placed centrally. Keep all trays and containers away from the back of the oven, as overbrowning of the food may occur.

For even browning, the maximum recommended size of a baking tray are:

- depth: 340 mm (13 3/8") by width: 340 mm (13 3/8") in the main oven
- depth: 321 mm (12 5/8") by width: 232 mm (9 1/8") in the tall oven.


When the oven is on, **DO NOT** leave the door open for longer than necessary, otherwise the knobs may get very hot.

- Always leave a "finger's width" between dishes on the same shelf. This allows the heat to circulate freely around them.
- To reduce fat splashing when you add vegetables to hot fat around a roast, dry them thoroughly or brush lightly with cooking oil.
- Where dishes may boil and spill over during cooking, place them on a baking tray.
- The 'Cook & Clean' oven liners (see 'Cleaning Your Cooker') work better when fat splashes are avoided. Cover meat when cooking with foil or use a roasting bag.
- Sufficient heat rises out of the oven while cooking to warm plates in the grill compartment.
- If you want to brown the base of a pastry dish, preheat the baking tray for 15 minutes before placing the dish in the centre of the tray.

## 7. Cooking Table

The oven control settings and cooking times given in the table below are intended to be used **as a guide only**. Individual tastes may require the temperature to be altered to provide a preferred result.


Food is cooked at lower temperature in a fan oven than in a conventional oven. When using recipes, reduce the fan oven temperature by 10°C and the cooking time by 5-10 minutes. The temperature in the fan oven does not vary with height in the oven so you can use any shelf.



| Food                                       | Conventional Oven<br>°C (Shelf Position) | Fan Oven<br>Temperature | Approximate Cooking Time                            |                                                                                                                                                                                                                                                                                               |
|--------------------------------------------|------------------------------------------|-------------------------|-----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Meat</b>                                |                                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
| Beef (no bone)                             | 160 (C)                                  | 150 °C                  | 30-35 minutes per 500g +30-35 minutes.              | Thoroughly thaw frozen joints before cooking. Meat may be roasted at 220°C (210°C for fan oven) and the cooking time adjusted accordingly. For stuffed and rolled meats, add approximately 10 minutes per 500g, or cook at 200°C (190°C) for 20 minutes then 160°C (150°C) for the remainder. |
|                                            | 200 (C)                                  | 190 °C                  | 20-25 minutes per 500g +20-25 minutes.              |                                                                                                                                                                                                                                                                                               |
| Lamb                                       | 160 (C)                                  | 150 °C                  | 30-35 minutes per 500g +30-35 minutes.              |                                                                                                                                                                                                                                                                                               |
|                                            | 200 (C)                                  | 190 °C                  | 25-30 minutes per 500g +25-30 minutes.              |                                                                                                                                                                                                                                                                                               |
| Pork                                       | 160 (C)                                  | 150 °C                  | 35-40 minutes per 500g +35-40 minutes.              |                                                                                                                                                                                                                                                                                               |
|                                            | 200 (C)                                  | 190 °C                  | 25-30 minutes per 500g +25-30 minutes.              |                                                                                                                                                                                                                                                                                               |
| <b>Poultry</b>                             |                                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
| Chicken                                    | 160 (C)                                  | 150 °C                  | 20-25 minutes per 500g +20-25 minutes.              | For stuffed poultry, you could cook at 200°C (190°C) for 20 minutes then 160°C (150°C) for remainder. Do not forget to include the weight of the stuffing. For fresh or frozen pre-packed poultry, follow instructions on the pack. Thoroughly thaw frozen poultry before cooking.            |
|                                            | 200 (C)                                  | 190 °C                  | 15-20 minutes per 500g +15-20 minutes.              |                                                                                                                                                                                                                                                                                               |
| Turkey                                     | 160 (C)                                  | 150 °C                  | 20 minutes per 500g +20 minutes.                    |                                                                                                                                                                                                                                                                                               |
|                                            | 200 (C)                                  | 190 °C                  | 15 minutes per 500g +15 minutes.                    |                                                                                                                                                                                                                                                                                               |
| Duck                                       | 160 (C)                                  | 150 °C                  | 25-30 minutes per 500g.                             |                                                                                                                                                                                                                                                                                               |
|                                            | 200 (C)                                  | 190 °C                  | 20 minutes per 500g.                                |                                                                                                                                                                                                                                                                                               |
| <b>Casserole</b>                           | 140-150 (C)                              | 130 °C-140 °C           | 2-4 hours according to recipe.                      |                                                                                                                                                                                                                                                                                               |
| <b>Yorkshire Pudding</b>                   | 220 (C)                                  | 210 °C                  | Large tins 30-35 minutes; individual 10-20 minutes. |                                                                                                                                                                                                                                                                                               |
| <b>Cake</b>                                |                                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
| Very rich fruit - Christmas, wedding, etc. | 140 (C/B)                                | 130 °C                  | 45-50 minutes per 500g of mixture.                  | Using the conventional oven: When two tier cooking leave at least one runner space between shelves. Position the baking tray with the front edge along the front of the oven shelf.                                                                                                           |
| Fruit 180 mm tin                           | 150 (C/B)                                | 140 °C                  | 2-2½ hours.                                         |                                                                                                                                                                                                                                                                                               |
| Fruit 230 mm tin                           | 150 (C/B)                                | 140 °C                  | Up to 3½ hours.                                     |                                                                                                                                                                                                                                                                                               |
| Madeira 180 mm                             | 160 (C/B)                                | 150 °C                  | 80-90 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Queen cakes                                | 190 (C/B)                                | 180 °C                  | 15-25 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Scones                                     | 220 (C/B)                                | 210 °C                  | 10-15 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Victoria sandwich                          |                                          |                         |                                                     | Up to three tiers can be cooked on, in a fan oven, at the same time. But make sure to leave at least one runner space between each shelf being cooked on.                                                                                                                                     |
| 180 mm tin                                 | 180 (C/B)                                | 170 °C                  | 20-30 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| 210 mm tin                                 | 180 (C/B)                                | 170 °C                  | 30-40 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| <b>Desserts</b>                            |                                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
| Shortcrust tarts                           | 200 (C/B)                                | 190 °C                  | 20-30 minutes on a preheated tray.                  | Up to three tiers can be cooked on, in a fan oven, at the same time. But make sure to leave at least one runner space between each shelf being cooked on.                                                                                                                                     |
| Fruit pies                                 | 200 (C/B)                                | 190 °C                  | 35-45 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Tartlets                                   | 200 (C/B)                                | 190 °C                  | 10-20 minutes according to size.                    |                                                                                                                                                                                                                                                                                               |
| Puff pastry                                | 210 (C/B)                                | 200 °C                  | 20-40 minutes according to size.                    |                                                                                                                                                                                                                                                                                               |
| Meringues                                  | 100 (C/B)                                | 90 °C                   | 2-3 hours.                                          |                                                                                                                                                                                                                                                                                               |
| Baked egg custard                          | 160 (C/B)                                | 150 °C                  | 45-60 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Baked sponge pudding                       | 180 (C/B)                                | 170 °C                  | 40-45 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| Milk pudding                               | 140-150 (C/B)                            | 130 °C-140 °C           | 2 to 3 hours.                                       |                                                                                                                                                                                                                                                                                               |
| <b>Bread</b>                               | 210 (C)                                  | 200 °C                  | 20-30 minutes.                                      |                                                                                                                                                                                                                                                                                               |
| <b>Fish</b>                                |                                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
|                                            | Fanned Grilling                          |                         |                                                     |                                                                                                                                                                                                                                                                                               |
| Fillet                                     | 190 (C/B)                                | 190 °C (C/B)            | 15-20 minutes                                       |                                                                                                                                                                                                                                                                                               |
| Whole                                      | 190 (C/B)                                | 190 °C (C/B)            | 15-20 minutes per 500g.                             |                                                                                                                                                                                                                                                                                               |
| Steak                                      | 190 (C/B)                                | 190 °C (C/B)            | Steaks according to thickness.                      |                                                                                                                                                                                                                                                                                               |


## 8. Cleaning Your Cooker

Fig. 8.1



A – Cap, B – Base

Fig. 8.2



Isolate the electricity supply before carrying out any major cleaning. Allow the cooker to cool.

**⚠ NEVER use paint solvents, washing soda, caustic cleaners, biological powders, bleach, chlorine based bleach cleaners, coarse abrasives or salt.**

**⚠ DO NOT mix different cleaning products – they may react together with hazardous results.**

All parts of the cooker can be cleaned with hot soapy water – but take care that no surplus water seeps into the appliance.

Remember to switch on the electricity supply and reset the clock before re-using the cooker.

### Hotplate Burners

The burner heads and caps can be removed for cleaning. Make sure they are absolutely dry before replacing them.

**⚠ DO NOT put the burner heads in a dishwasher.**

When replacing a burner head, make sure that it locates properly within the base (**Fig. 8.1**). If you look at the bottom of the burner head you will see two 'pips' – these fit into the two notches in the burner base (**Fig. 8.2**).

Check burner ports are not blocked. If a blockage occurs, remove stubborn particles using a piece of fuse wire.

### The Griddle *(optional extra)*

Always clean the griddle after use. Allow it to cool completely before removing. Immerse the griddle plate in hot soapy water. Use a soft cloth or, for stubborn stains, a nylon washing up brush.

**NOTE:** If the griddle is washed in a dishwasher then some dishwasher residue may appear on the back. This is normal and will not affect the performance of your griddle.

## Glide-out Grill

**⚠ Before you remove any of the grill parts for cleaning, make sure that they are cool, or use oven gloves.**

**⚠ DO NOT use any abrasive substances.**

The grill pan and trivet should be washed in hot soapy water. Alternatively, the grill pan can be washed in a dishwasher.

After grilling meats or any foods that soil, leave to soak for a few minutes in the sink immediately after use. Stubborn particles may be removed from the trivet using a nylon brush.

The grill pan can be easily removed for cleaning as follows:

Remove the grill pan support frame by pulling the grill pan forward (**Fig. 8.3**).

Lift the grill pan clear of the support frame. The support frame is held to the side rails by two clips on each side (**Fig. 8.4**).

For each side, support the side rail with one hand and with the other hand lift the frame up and out of the side clips (**Fig. 8.5**).

For safety, push the side rails back into the grill chamber.

If you need to remove the side rails to allow cleaning of the grill chamber, you can unhook them from the grill chamber sides (**Fig. 8.6**) and wipe the sides clean with a soft cloth and mild detergent.

**⚠ DO NOT put the side runners in a dishwasher.**

Once you have finished, hook the side rails back onto the sides of the chamber. To refit the frame, pull the side rails forward and, for each side in turn, support the side rail and press the frame down into the side rails. Replace the grill pan.

## Control Panel and Doors

Avoid using any abrasive cleaners including cream cleaners, on brushed stainless steel surfaces. For best results, use a liquid detergent.

The control panel, knobs and doors should only be cleaned with a soft cloth wrung out in clean hot soapy water – but take care that no surplus water seeps into the appliance.

After cleaning, polish with a dry cloth.




Fig. 8.3




Fig. 8.4




Fig. 8.5





Fig. 8.6

**Fig. 8.7**



## Ovens

### 'Cook & Clean' Panels

The ovens have panels which have been coated with a special enamel that partly cleans itself. This does not stop all marks on the lining, but helps to reduce the amount of manual cleaning needed.

The Cook & Clean panels work better above 200 °C. If you do most of your cooking below this temperature, occasionally remove the panels and wipe with a lint free cloth and hot soapy water. The panels should then be dried and replaced and the oven heated at 200 °C for about one hour. This will make sure that the Cook & Clean panels are working effectively.

**⚠ DO NOT use steel wool, oven cleaning pads, or any other materials that will scratch the surface.**

### Removing the Main Oven Linings

Some of the lining panels can be removed for cleaning.

If you wish to clean the enamel interior of the oven, you will need to remove the shelves before removing the 'Cook & Clean' panels. You do not have to remove the support brackets to remove the panels. Lift each panel upward and slide forward off the support brackets (**Fig. 8.7**).

Once the panels have been removed, the oven enamel interior can be cleaned.

Refit in the reverse order.

## Cleaning Table

Cleaners listed are available from supermarkets or electrical retailers as stated.

For enamelled surfaces use a cleaner that is approved for use on vitreous enamel.

Regular cleaning is recommended. For easier cleaning, wipe up any spillages immediately.

| Hotplate                                                             |                                           |                                                                                                                                                                                                    |
|----------------------------------------------------------------------|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                                                                 | Finish                                    | Recommended Cleaning Method                                                                                                                                                                        |
| Hob top (including burner heads and caps)                            | Enamel, stainless steel, aluminium, brass | Hot soapy water, soft cloth. Any stubborn stains remove gently with a nylon scourer.                                                                                                               |
| Ceramic/Induction hob                                                | Toughened glass                           | Hot soapy water; cream cleaner/scourer if necessary.                                                                                                                                               |
| Griddle plate (some models only)                                     | Non-stick surface                         | Allow to cool. Wash in hot soapy water. Do not use abrasive cleaners/scourers. Dishwasher.                                                                                                         |
| Warming zone (some models only)                                      | Toughened glass                           | Hot soapy water, cream cleaner/scourer if necessary.                                                                                                                                               |
| Outside of Cooker                                                    |                                           |                                                                                                                                                                                                    |
| Part                                                                 | Finish                                    | Recommended Cleaning Method                                                                                                                                                                        |
| Door, door surround and storage drawer exterior                      | Enamel or paint                           | Hot soapy water, soft cloth.<br>Any stubborn stains, remove gently with a liquid detergent.                                                                                                        |
|                                                                      | Stainless steel                           | E-cloth (electrical retailers) or microfibre all-purpose cloth (supermarket).                                                                                                                      |
| Sides and plinth                                                     | Painted surface                           | Hot soapy water, soft cloth.                                                                                                                                                                       |
| Splashback/rear grille                                               | Enamel or stainless steel                 | Hot soapy water, soft cloth. Cream cleaner, with care, if necessary.                                                                                                                               |
| Control panel                                                        | Paint, enamel or stainless steel          | Warm soapy water. Do not use abrasive cleaners on lettering.                                                                                                                                       |
| Control knobs/handles & trims                                        | Plastic/chrome, copper or lacquered brass | Warm soapy water, soft cloth.                                                                                                                                                                      |
|                                                                      | Brass                                     | Brass polish.                                                                                                                                                                                      |
| Oven door glass/glass lid                                            | Toughened glass                           | Hot soapy water, cream cleaner/scourer if necessary.                                                                                                                                               |
| Oven and Grill                                                       |                                           |                                                                                                                                                                                                    |
| Part                                                                 | Finish                                    | Recommended Cleaning Method                                                                                                                                                                        |
| Sides, floor & roof of oven NOT COOK & CLEAN OVEN PANELS (see below) | Enamel                                    | Any proprietary oven cleaner that is suitable for enamel.<br><br>CAUTION: CORROSIVE/CAUSTIC OVEN CLEANERS: FOLLOW MANUFACTURER'S INSTRUCTIONS.<br><br>Do not allow contact with the oven elements. |
| Cook & Clean oven panels (some models only)                          | Special enamel that partly cleans itself  | This surface cleans itself at 200 °C and above, or the panels can be removed and washed with hot soapy water and a nylon brush (see 'The Ovens' in 'Cleaning your Cooker').                        |
| Oven shelves, Handyrack, Grill trivet, Handyrack rack                | Chrome                                    | An oven interior cleaner that is suitable for chrome. Soap filled pad. Dishwasher.                                                                                                                 |
| Grill pan/meat tin (some models only)                                | Enamel                                    | Hot soapy water. Soap filled pad. Dishwasher.                                                                                                                                                      |

## 9. Troubleshooting

---

### Hotplate/Cooktop ignition or hotplate burners faulty

Is the power on? Is the clock illuminated?

If not, there maybe something wrong with the power supply.

Are the sparker (ignition electrode) or burner slots blocked by debris? See (**Fig. 9.1** and **Fig. 9.2**).

Are the burner trim and caps correctly located? See the section on 'Cleaning'.

### Hotplate/Cooktop burners will not light

Make sure that the burner parts have been replaced correctly after wiping or removing for cleaning.

Check that there is not a problem with your gas supply. You can do this by making sure that other gas appliances you may have are working.

### Do the burners spark when you push the button?

If not, verify that the power is on by checking that the clock is illuminated.

### Steam is coming from the oven

When cooking foods with high water content (e.g. oven fries) there may be some steam visible at the rear grille.

Take care when opening the oven door, as there may be a momentary puff of steam when the oven door is opened. Stand well back and allow any steam to disperse.

### What cleaning materials are recommended for the cooker?

See the 'Cleaning' section for recommended cleaning materials.

 **Never use caustic or abrasive cleaners as these will damage the surface.**

### An oven fan is noisy

The note of the oven fan may change as the oven heats up – this is perfectly normal.

### If there is an installation problem and I don't get my original installer to come back to fix it who pays?

You do. Service organizations will charge for their call outs if they are correcting work carried out by your original installer. It is in your interest to track down your original installer.

### Power failure

In the event of a failure in the electrical supply, remember to reset the clock to make sure that the timed oven continues to operate.

### Food is cooking too slowly, too quickly, or burning

Cooking times may differ from your previous oven.

Check that you are using the recommended temperatures and shelf positions – see the oven cooking guide. The oven control settings and cooking times are intended to be used only as a guide.

Individual tastes may require the temperature to be altered either way, to get the results you want.

### The oven is not cooking evenly

**DO NOT** use a baking tray with dimensions larger than those specified in the section on 'General Oven Tips'.

If you are cooking a large item, be prepared to turn it round during cooking.

If two shelves are used, check that space has been left for the heat to circulate. When a baking tray is put into the oven, make sure that it is placed centrally on the shelf.

Check that the door seal is not damaged and that the door catch is adjusted so that the door is held firmly against the seal.

A dish of water when placed on the shelf should be the same depth all over. (For example, if it is deeper at the back, then the back of the cooker should be raised up or the front lowered.) If the cooker is not level, arrange for your supplier to level it for you.

### Oven not coming on

Is the power on? Is the clock illuminated? If not, there may be something wrong with the power supply.

Is the cooker supply on at the isolator switch?

Has the time of day been set?

### The timed oven is not coming on when automatic cooking

Has the oven knob been left in the OFF position by mistake?

### Oven temperature getting hotter as the cooker gets older

If turning the temperature down using the oven control knob has not worked, or has only worked for a short time, then you may need a new thermostat. This should be fitted by a qualified service person.

### Oven light is not working

The bulb has probably burnt out. You can buy a replacement bulb (which is not covered under the warranty) from a good electrical shop. Ask for a 40W - 230V halogen lamp (G9) (**Fig. 9.3**).

Before removing the existing bulb, turn off the power supply and make sure that the oven and bulb have cooled. Open the oven door and remove the oven shelves.

Remove the bulb cover by turning it a quarter turn, counter-clockwise. It may be very stiff (**Fig. 9.4**).

Pull the existing bulb to remove it. When handling the replacement bulb, avoid touching the glass with your fingers, as oils from your hands can cause premature failure. Push, click in the replacement bulb.

Replace the bulb cover by turning it a quarter turn, clockwise. Turn on the circuit breaker and check that the bulb now lights.

### The left-hand oven door is misaligned

The bottom hinge of the left-hand oven door can be adjusted to alter its angle (**Fig. 9.5**).

Loosen the bottom hinge fixing screws and use the notch and a flat bladed screwdriver to move the position of the hinge to set the hinge position (**Fig. 9.6**).

Retighten the hinge screws.

**NOTE:** The tall oven door cannot be adjusted

### The fascia gets hot when I use the oven or grill

The cooker is cooled by a fan. If the fascia becomes excessively hot when the cooker is in use then the cooling fan may have failed. Should this occur please contact your installer, a qualified repair engineer or Customer Service to arrange for its repair.


### The knobs get hot when I use the oven or the grill. Can I avoid this?

Yes, this is caused by heat rising from the oven or the grill, and heating them up. **DO NOT** leave the oven door open.


Make sure that the grill pan is pushed right back to the 'back stop' when grilling.

Always grill with the grill compartment door open.


**Fig. 9.1**




**Fig. 9.2**




**Fig. 9.3**



**Fig. 9.4**




**Fig. 9.5**



Effect of hinge adjustment – exaggerated for clarity

**Fig. 9.6**



## INSTALLATION

Check the appliance is electrically safe and gas sound when you have finished.

# 10. Installation

## Dear Installer

Before you start your installation, please complete the details below, so that, if your customer has a problem relating to your installation, they will be able to contact you easily.

|                                     |
|-------------------------------------|
| <b>Installer's Name</b>             |
|                                     |
| <b>Installer's Company</b>          |
|                                     |
| <b>Installer's Telephone Number</b> |
|                                     |
| <b>Appliance Serial Number</b>      |
|                                     |

## Safety Requirements and Regulations

-  **This cooker must be installed in accordance with the relevant instructions in this booklet, with the relevant national and local regulations, and with the local gas and electricity supply companies' requirements.**
-  **This cooker is a Class 2 Subclass 1 appliance.**
-  **Before installation, make sure that the cooker is suitable for your gas type and supply voltage. See the data badge.**
-  **The appliance must be installed in accordance with the regulations in force and only in a well ventilated space.**
-  **Read the instructions before installing or using this appliance.**
-  **In your own interest and that of safety, it is law that all gas appliances be installed by competent persons. Failure to install the appliance correctly could invalidate any warranty or liability claims and lead to prosecution.**
-  **This appliance can be converted for use on another gas.**

## In the UK the cooker must be installed in accordance with:

- All relevant British Standards / Codes of Practice, in particular BS 5440 Part 2.
- For Natural Gas – BS 6172 and BS 6891.
- For LP Gas – BS 5482-1 (when the installation is in a permanent dwelling), BS 5482-2 (when the installation is in a caravan or other non-permanent dwelling), or BS 5482-3 (when the installation is in a boat).
- The Gas Safety (Installation and Use) regulations.
- The relevant Building / IEE regulations.

## In the Republic of Ireland the cooker must be installed in accordance with:

The installation must be carried out by a competent person and installed in accordance with the current edition of IS 813 "Domestic Gas Installations", the current Building Regulations and reference should be made to the current ETCI rules for electrical installation.

## Provision of Ventilation

This appliance is not connected to a combustion products evacuation device. Particular attention shall be given to the relevant requirements regarding ventilation.

All rooms require a window that can be opened, or equivalent, while some rooms require a permanent vent in addition to the window.

## In the UK:

The room containing the cooker should have an air supply in accordance with BS 5440 Part 2. All rooms require an openable window or equivalent, while some rooms require a permanent vent in addition to the openable window. The cooker should not be installed in a bedsitting room with volume less than 20 m<sup>3</sup>. If it is installed in a room of volume less than 5 m<sup>3</sup> an air vent of effective area 100 cm<sup>2</sup> is required; if it is installed in a room of volume between 5 m<sup>3</sup> and 10 m<sup>3</sup>, an air vent of effective area 50 cm<sup>2</sup> is required; while if the volume exceeds 11 m<sup>3</sup>, no air vent is required.

If there are other fuel burning appliances in the same room, BS 5440 Part 2 should be consulted to determine the requisite air vent requirements.

## In the Republic of Ireland:

Reference should be made to the current edition of IS 813, which makes clear the conditions that must be met to demonstrate that sufficient ventilation is available.

## INSTALLATION

**Check the appliance is electrically safe and gas sound when you have finished.**

### Location of Cooker

The cooker may be installed in a kitchen/kitchen diner but NOT in a room containing a bath or shower.

**This appliance is designed for domestic cooking only. Use for any other purpose could invalidate any warranty or liability claim.**

**Note:** An appliance for use on LPG must not be installed in a room or internal space below ground level, e.g. in a basement.

### Conversion

This appliance is supplied set for G20 20 mbar Cat II<sub>2H3+</sub>.

A conversion kit for another gas is available for the cooker.

If the appliance is to be converted to another gas we recommend that this is carried out before installation.

After converting the appliance, please attach the Gas Conversion sticker over the appropriate area of the data badge – this will identify the gas type for which the appliance is now set.








**You will need the following equipment to complete the cooker installation satisfactorily:**

- Stability bracket: If the cooker is to be supplied with gas through a flexible hose, a stability bracket or chain **MUST** be fitted.  
**These are not supplied with the cooker** but are available at most builders' merchants.
- Gas pressure tester/manometer.
- Flexible gas hose: Must be in accordance with the relevant standards.
- Multimeter: For electrical checks.

**You will also need the following tools:**

1. Electric drill
2. Masonry drill bit (only required if fitting the cooker on a stone or concrete floor)
3. Wall plugs (only required if fitting the cooker on a stone or concrete floor)
4. Steel tape measure
5. Cross head screwdriver
6. Flat head screwdriver
7. Spirit level
8. Pencil
9. Adjustable spanner
10. Screws for fitting stability bracket
11. 13 mm spanner or socket wrench


### Checking the parts:

| Pan supports                                                                         | Grill pan and trivet                                                                 |
|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
|    |   |
| 2 telescopic shelves                                                                 | Deluxe tray                                                                          |
|    |   |
| 2-piece plinth                                                                       | Meat probe                                                                           |
|   |  |
| Stability location bracket                                                           |                                                                                      |
|  |                                                                                      |

## INSTALLATION

Check the appliance is electrically safe and gas sound when you have finished.

Fig. 10.1



### Positioning the Cooker

**Fig. 10.1** and **Fig. 10.2** show the minimum recommended distance from the cooker to nearby surfaces.

The cooker should not be placed on a base.

The hotplate surround should be level with, or above, any adjacent work surface. A gap of 75 mm should be left between each side of the cooker **ABOVE** the hotplate level and any adjacent vertical surface.

For non-combustible surfaces (such as unpainted metal or ceramic tiles), this can be reduced to 25 mm.

A minimum space of 800 mm is required between the top of the hob and a horizontal combustible surface.

*\*Any cookerhood should be installed in accordance with the hood manufacturer's instructions.*


*\*\*Any splashback must be fitted in accordance with the manufacturers instructions. Allowance should be made for the additional height of the flue trim, which is fitted to the cooker hob.*

Surfaces of furniture and walls at the sides and rear of the appliance should be heat, splash and steam resistant. Certain types of vinyl or laminate kitchen furniture are particularly prone to heat damage and discolouration. We cannot accept responsibility for damage caused by normal use of the cooker to any material that de-laminates or discolours at temperatures less than 65°C above room temperature.

**DO NOT** box the cooker in – it must be possible to move the cooker in and out for cleaning and servicing.

If the cooker is near a corner of the kitchen, a clearance of 130 mm is required to allow the oven doors to open (**Fig. 10.3**). The actual opening of the doors is slightly less, but this allows for some protection of your hand as you open the door.

Fig. 10.3



### Moving the Cooker

**⚠ On no account try and move the cooker while it is plugged into the electricity supply.**

**⚠ The cooker is very heavy, so take great care.**


We recommend that two people manoeuvre the cooker. Make sure that the floor covering is firmly fixed, or removed, to prevent it being disturbed when moving the cooker around.

To help you, there are two levelling rollers at the back, and two screw-down levelling feet at the front.

Remove the polystyrene base pack. From the front, tilt the cooker backwards and remove the front half of the polystyrene base (**Fig. 10.4**).

Repeat from the back and remove the rear half of the polystyrene base.

Fig. 10.4



## INSTALLATION


**Check the appliance is electrically safe and gas sound when you have finished.**

### Lowering the Two Rear Rollers

To adjust the height of the rear of the cooker, first fit a 13 mm spanner or socket wrench onto the hexagonal adjusting nut (**Fig. 10.5**). Rotate the nut – clockwise to raise – counter-clockwise to lower.

Make 10 complete (360°) turns clockwise.

Make sure you lower BOTH REAR ROLLERS.




### Completing the Move

Unfold the rear edge of the cardboard base tray. Open the oven doors so that you can get a good grip on the bottom of the fascia panel as you move the oven (**Fig. 10.6**).

Carefully push the cooker backwards off the base tray. Remove the base tray.

Position the cooker close to its final position, leaving just enough space to get behind it.

**⚠ DO NOT use the door handles or control knobs to manoeuvre the cooker.**





### Fitting the Stability Bracket or Chain

Unless otherwise stated, a cooker using a flexible gas connector must be secured with a suitable stability device.

Suitable stability devices are shown in **Fig. 10.7** and **Fig. 10.8**.

If you are using a stability chain (**Fig. 10.7**) then the chain should be kept as short as is practicable and fixed firmly to the rear of the cooker.

If you are using a stability bracket; first attach the bracket location device to the rear of the cooker (**Fig. 10.8**). Then adjust the bracket to engage through the slot of the device (**Fig. 10.9** and **Fig. 10.10**).





### Repositioning the Cooker Following Connection

If you need to move the cooker once it has been connected then you need to unplug it and, having gripped under the fascia panel and lifted the front of the cooker slightly (**Fig. 10.6**), you need to check behind the cooker to make sure that the gas hose is not caught.

As you progress, make sure that both the electricity cable and gas hose always have sufficient slack to allow the cooker to move.

*With a stability chain fitted, release it as you ease the cooker out. Do not forget to refit it when you replace the cooker.*

When you replace the cooker, again check behind to make sure that the electricity cable and gas hose are not caught or trapped.



## INSTALLATION

Check the appliance is electrically safe and gas sound when you have finished.

Fig. 10.11




Fig. 10.12





Fig. 10.13



### Conversion to Another Gas

If the appliance is to be converted to another gas do the conversion at this point. See the conversion section of these instructions.

### Fitting the Handles

The handles will require fitting as follows:

Remove the existing M5 screws from the doors. Keep them in a safe place (**Fig. 10.11**).

Position the handle (**Fig. 10.12**) and screw in the M5 screws (**Fig. 10.13**).

### Levelling

You are recommended to use a spirit level on a shelf in one of the ovens to check for level.

Place the cooker in its intended position, taking care not to twist it within the gap between the kitchen units as damage may occur to the cooker or the units.

The front feet and rear rollers can be adjusted to level the cooker.

To adjust the height of the rear of the cooker use a 13 mm spanner or socket wrench to turn the adjusting nuts at the front bottom corners of the cooker.

To set the front, turn the feet bases to raise or lower.

## INSTALLATION

**Check the appliance is electrically safe and gas sound when you have finished.**

### Gas Connection

This must be in accordance with the relevant standards.

The flexible hose (not supplied with the cooker) must be in accordance with the relevant standards. Hoses may be purchased at most builders' merchants.

**In the UK, we recommend that a Micropoint gas hose is used when installing this appliance.**

The gas supply must terminate with a side facing pipe-elbow and a downward facing bayonet-pipe-connection (**Fig. 10.14**).

The connector is located just below the hotplate level at the rear of the cooker. If in doubt contact your supplier.

The rear cover boxes limit the position of the supply point.

Because the height of the cooker can be adjusted and each connection is different, it is difficult to give precise dimensions.

Although a 900 mm hose can be used, a 1250 mm hose will allow slightly more flexibility in the positioning of the bayonet and make moving the cooker easier.

The hose should be fitted so that both inlet and outlet connections are vertical so that the hose hangs downwards in a 'U' shape.

Ideally the hose supply connection should be within the shaded area 'A' (**Fig. 10.15**).

For Natural Gas, the flexible hose must be in accordance with BS 669. For LP Gas, it should be capable of 50 mbar pressure and 70 °C temperature rise. If in doubt contact, your supplier.

Screw connect the threaded end of the hose into the gas inlet.

After completing the gas connection, make sure that the cooker is gas sound with a pressure test.

### Pressure Testing

The gas pressure can be measured at one of the hotplate burner injectors (not a wok burner).


Lift off a burner head. Fit the pressure gauge to the injector. Turn on and light one of the other hotplate burners.

Turn on the control knob for the burner with the pressure gauge fitted to let gas through.


**See the data badge for test pressures.**

Turn off the burners. Make sure that you reassemble the burner top in the correct way on the burner body.

**Fig. 10.14**




**Fig. 10.15**



## INSTALLATION

Check the appliance is electrically safe and gas sound when you have finished.

Fig. 10.16



## Electrical Connection


The cooker must be installed by a qualified electrician, in accordance with all relevant British Standards/Codes of Practice (in particular BS 7671), or with the relevant national and local regulations.

### Current Operated Earth Leakage Breakers

The combined use of your cooker and other domestic appliances may cause nuisance tripping, so we recommend that the cooker is protected on an individual RCD (Residual Current Device) or RCBO (Residual Current Breaker with Overload).

**IF IN DOUBT, PLEASE CONSULT A SUITABLY QUALIFIED ELECTRICIAN.**

Fig. 10.17



### ⚠ WARNING: THE APPLIANCE MUST BE EARTHED.

**Note:** The cooker must be connected to the correct electrical supply as stated on the voltage label on the cooker, through a suitable cooker control unit incorporating a double-pole switch, having a contact separation of at least 3 mm in all poles.

### ⚠ The cooker **MUST NOT** be connected to an ordinary domestic power point.

Access to the mains terminal is gained by removing the electrical terminal cover box on the back panel. Connect the mains cable to the correct terminals for your electrical supply type (**Fig. 10.16** and **Fig. 10.17**). Check that the links are correctly fitted and that the terminal screws are tight. Secure the mains cable using the cable clamp.

## INSTALLATION

Check the appliance is electrically safe and gas sound when you have finished.

### Final Checks

#### Hob Check

Check each cooking zone in turn. Be sure to use pans of the correct size and material.

#### Grill Check

Turn on the grill control and check that the grill heats up.

#### Oven Check

Set the clock as described earlier, and then turn on the ovens. Check the oven fans start to turn and that the ovens heat up.

### Final Fitting

#### Fitting the 2-piece Plinth

Fit the inner plinth to the bottom front of the cooker using the 5 screws provided (3x M5 screws in the lower edge, 2x No.8 screws in the each end) (**Fig. 10.18**).

Loosen the 2 screws in the front of the inner plinth.

Locate the 2 slotted brackets on the inside of the outer plinth onto the 2 screws (**Fig. 10.19**).

**Note:** To aid the fitting of the outer plinth, we advise that you open the doors and place the wings of the outer plinth over the side panels at approximately a 45° angle (**Fig. 10.20**). This will aid location of the outer plinth onto the retaining screws.

Using a suitable screwdriver through the slots in the outer plinth, tighten the 2 screws to secure.

The height of the outer plinth can be adjusted by loosening the 2 retaining screws and sliding it up or down to suit and then retightening the screws.




#### Fitting the Splashback

Position the splashback on the rear of the hotplate and secure with the screws supplied.

### Customer Care


**Installer:** Please complete your details in this guide, inform the user how to operate the cooker and hand over the instructions.

**Thank you.**



## 11. Conversion to LP Gas

Fig. 11.1



A - Burner head, B - Base, C - Brass venturi, D - Burner ring

Fig. 11.2




Fig. 11.3





Fig. 11.4



Check the 'Technical Data' section at the back of the book that the hob is convertible to the gas you want to use.

A suitably competent person must perform the conversion. After conversion the installation must comply with the relevant regulations and also the local electricity supply company requirements. Read the instructions before converting this appliance.

- ⚠ Failure to convert the appliance correctly could invalidate any warranty or liability claims and lead to prosecution.**
- ⚠ When servicing or replacing gas-carrying components disconnect from the gas supply before starting operation. Check the appliance is gas sound after completion.**
- ⚠ DO NOT use reconditioned or unauthorised gas controls.**
- ⚠ Disconnect from the electricity and gas supply before servicing.**
- ⚠ Before electrical reconnection, check that the appliance is electrically safe.**

### Injectors

Remove pan supports and burner heads.

Remove burner heads. Undo the large brass nuts and remove the brass venturis and brass rings (**Fig. 11.1**).

Use a long box spanner to access and remove the old injectors.

Using the rubber tubing, provided in the conversion kit, fit over the end of the socket wrench (**Fig. 11.2**).

Carefully push the open end of the tubing onto the orifice (**Fig. 11.3**). Unscrew the orifice fully and lift clear of the cooktop.

Save the injectors removed from the appliance for possible future use. Fit the new injectors, see the table 'Technical Data' section at the back of this book for the correct type.

Insert the new orifice into the open end of the rubber tube which is attached to the socket wrench. Screw into the orifice carrier as far as possible and lift the socket wrench away (**Fig. 11.4**).

Remove the rubber tubing from the socket wrench and tighten all of the orifices.

Replace the rings on the burners. Screw in the hexagon headed venturi to make fitting the burners easier. **DO NOT** tighten yet.

When all the burner bases and venturis have been fitted tighten the venturi nuts.

## Bypass Screw Adjustment

The valves in this cooker are fitted with adjustable bypass screws. The cooker is supplied with the bypass screws set for Natural gas. For LPG conversion the bypass screws must be screwed all the way down.

It may be possible to adjust the bypass screw by simply removing the control knobs (**Fig. 11.5**). If however you are unable to access the bypass screw using a suitable screwdriver, you will need to remove the control panel, please refer to section 'Removing the Control Panel' below.

## Removing the Control Panel

Pull off all the control knobs and remove the fixing screws underneath the control panel (**Fig. 11.6**).

The control panel will drop down slightly. Clear the holes from the inner panel and pull the control panel forward. Take care not to damage or strain the wiring.

Turn the bypass screw on each control clockwise to the stop (**Fig. 11.7**).

## Stick on Label

Stick the LP gas label over the natural gas part of the appliance data label.

## Pressure Testing

Connect the appliance to the gas supply.

The gas pressure can be measured at one of the hotplate burner injectors (not the Wok burner).

Lift off a burner head. Fit the pressure gauge to the jet. Turn on and light one of the other hotplate burners. Turn on and press in the control knob for the burner with the pressure gauge fitted.


See the **Technical Data** section at back of the book for the correct size. After checking the pressure, turn off the taps and replace the burner head.

Reassemble burner top, making sure it is reassembled in the correct way on the burner body.


Check operation of all the burners.

Check the appliance is gas sound.


**Fig. 11.5**




**Fig. 11.6**



**Fig. 11.7**



# 12. Circuit Diagram



## Key

The connections shown in the circuit diagram are for single-phase. The ratings are for 230 V 50 Hz.

| Code | Description                         |
|------|-------------------------------------|
| X01  | Grill Front Switch                  |
| X02  | Grill Energy Regulator              |
| X03  | Left Hand Grill Element             |
| X04  | Right Hand Grill Element            |
| X05  | Left Hand Oven Thermostat           |
| X06  | Left Hand Oven Multifunction Switch |
| X07  | Left Hand Oven Front Switch         |
| X08  | Left Hand Oven Base Element         |
| X09  | Left Hand Oven Fan Element          |
| X10  | Left Hand Oven Top Outer Element    |
| X11  | Left Hand Oven Top Inner Element    |
| X12  | Right Hand Oven Thermostat          |
| X14  | Right Hand Oven Front Switch        |
| X15  | Right Hand Oven Fan Element         |

| Code | Description                |
|------|----------------------------|
| X16  | Oven Fan                   |
| X17  | Clock / Timer              |
| X24  | Cooling Fan                |
| X25  | Cooling Fan Thermal Preset |
| X26  | Neon                       |
| X27  | Thermal Cut-Out            |
| X28  | Ignition Switches          |
| X30  | Spark Generator            |
| X31  | Oven Light                 |
| X32  | Oven Light Switch          |
| X42  | Meat Probe Socket          |
| X43  | Cooling Fan Test Switch    |
| X44  | Mains Terminal Block       |

| Code | Colour       |
|------|--------------|
| b    | Blue         |
| br   | Brown        |
| bk   | Black        |
| or   | Orange       |
| r    | Red          |
| v    | Violet       |
| w    | White        |
| y    | Yellow       |
| g/y  | Green/yellow |
| gr   | Grey         |

## 13. Technical Data

**THIS COOKER IS CATEGORY:** II<sub>2</sub>H<sub>3</sub>+

It is supplied set for group H natural gas. A conversion kit from NG to LP is available for the cooker.

**INSTALLER:** Please leave these instructions with the User.

**DATA BADGE LOCATION:** Cooker back, serial number repeater badge below oven door opening.

**COUNTRY OF DESTINATION:** GB, IE.

### Connections

| Gas (Rp ½ at rear right-hand side) |         | Electric       |
|------------------------------------|---------|----------------|
| Natural Gas                        | 20 mbar | 230/400V 50 Hz |
| Butane                             | 29 mbar |                |
| Propane                            | 37 mbar |                |

See the appliance badge for test pressures.

### Dimensions

|                                   |                                                    |                |
|-----------------------------------|----------------------------------------------------|----------------|
| Model                             | AGA Masterchef Deluxe 90 Dual Fuel                 |                |
| Overall height                    | minimum 905 mm                                     | maximum 930 mm |
| Overall width                     | 900 mm                                             |                |
| Overall depth                     | 608 mm excluding handles, 694 mm including handles |                |
| Minimum height above the hotplate | 650 mm                                             |                |

### Hotplate Ratings

| Hotplate           | Bypass Screw* | Natural Gas G20 20 mb |          | L.P. Gas 29 / 37 mb |          |
|--------------------|---------------|-----------------------|----------|---------------------|----------|
|                    |               |                       | Injector |                     | Injector |
| Centre burner      | 57            | 5.0 kW                | 165      | 5.0 kW (364g/h)     | 107      |
| Large burner       | 40            | 3.0 kW                | 120      | 3.0 kW (218g/h)     | 82       |
| Semi Rapide/ small | 32            | 1.70 kW               | 95       | 1.70 kW (124g/h)    | 64       |

\* The valves in this cooker are fitted with adjustable bypass screws. The cooker is supplied with the bypass screws set for Natural gas. For LPG conversion the bypass screws must be screwed all the way down.

#### Hotplate energy saving tips

Use cookware with a flat base.  
Use the correct size cookware.  
Use cookware with a lid.  
Minimise the amount of liquid or fat.  
When liquid starts boiling, reduce the setting.  
Consumption is based on G30.

#### Oven energy saving tips

Cook meals together, if possible.  
Keep the pre-heating time short.  
Do not lengthen cooking time.  
Do not open the oven door during the cooking period.  
Do not forget to turn the appliance off at the end of cooking.

## Hotplate Efficiency Data

|                                             |                   |
|---------------------------------------------|-------------------|
| Brand                                       | AGA               |
| Model Identification                        | Masterchef Deluxe |
| Size                                        | 90                |
| Type                                        | Dual Fuel         |
| Type of Hob                                 | GAS               |
| Number of gas burners                       | 5                 |
| Auxiliary / Small Burner (EE gas burner)    | -                 |
| Semi Rapide / Medium Burner (EE gas burner) | 60%               |
| Semi Rapide / Medium Burner (EE gas burner) | -                 |
| Rapide / Large Burner (EE gas burner)       | 58%               |
| Rapide / Large Burner (EE gas burner)       | 58%               |
| Rapide / Large Burner (EE gas burner)       | 58%               |
| Ultra Rapide / Large Burner (EE gas burner) | 55%               |
| Wok (EE gas burner)                         | -                 |
| Wok (EE gas burner)                         | -                 |
| Hotplate EE gas hob (*)                     | 57%               |

\*Information marked thus (\*) is not required with mixed fuel hobs

## Oven Data

|                                                          |             |                   |
|----------------------------------------------------------|-------------|-------------------|
| Brand                                                    |             | AGA               |
| Model identification                                     |             | Masterchef Deluxe |
| Type of oven                                             |             | Electric          |
| Mass                                                     | kg          | 114               |
| Number of cavities                                       |             | 2                 |
| <b>Left-hand Efficiency</b>                              |             |                   |
| Fuel type                                                |             | Electric          |
| Cavity type                                              |             | Multifunction     |
| Power - conventional                                     |             | 2.2               |
| Power - forced air convection                            |             | 2.5               |
| Volume                                                   | Litres      | 79                |
| Energy consumption (electricity) - conventional          | kWh / cycle | 1.01              |
| Energy consumption (electricity) - forced air convection | kWh / cycle | 0.88              |
| Energy efficiency index - conventional                   |             | 114               |
| Energy efficiency index - forced air convection          |             | 100               |
| Energy class                                             |             | A                 |
| <b>Right-hand Efficiency</b>                             |             |                   |
| Fuel type                                                |             | Electric          |
| Cavity type                                              |             | Fanned            |
| Power - conventional                                     |             | -                 |
| Power - forced air convection                            |             | 2.5               |
| Volume                                                   | Litres      | 67                |
| Energy consumption (electricity) - conventional          | kWh / cycle | -                 |
| Energy consumption (electricity) - forced air convection | kWh / cycle | 0.79              |
| Energy efficiency index - conventional                   |             | -                 |
| Energy efficiency index - forced air convection          |             | 95.6              |
| Energy class                                             |             | A                 |

|                                     |        |
|-------------------------------------|--------|
| <b>Additional Information</b>       |        |
| The oven complies with EN 60350-1   |        |
| Maximum output @ 230V 50Hz          |        |
| Conventional                        | 2.2 kW |
| Multifunction                       | 2.5 kW |
| Multifunction (with Rapid Response) | 3.7 kW |
| Forced Air Convection               | 2.5 kW |
| Grill                               | 2.3 kW |
| Slow Oven                           | -      |
| Bread Proving Drawer                | -      |

|                                                                                                               |        |
|---------------------------------------------------------------------------------------------------------------|--------|
| <b>Maximum total electrical load at 230 V</b> (approximate total including hob, oven lights, oven fan, etc.): | 8.6 kW |
|---------------------------------------------------------------------------------------------------------------|--------|

## NOTE

---

## NOTE

---

## NOTE

---

## CUSTOMER SERVICE

If you have any product enquiries, or in the event of a problem with your appliance once it has been installed, please telephone **01952 643149**

## CUSTOMER SERVICE LINES OPEN:

Monday to Friday 9am – 5pm

## WARRANTY

An AGA Masterchef Deluxe has a five-year parts and one-year labour warranty.

## ALSO PART OF THE AGA COLLECTION...



### 4-IN-1 TAP COLLECTION

**AGA has long been known for delivering great design, outstanding functionality and, in recent years, cutting-edge technology. Now the range has been extended to take in a collection of innovative kitchen taps.**

The AGA 4-in-1 Tap offers all the benefits of a kitchen mixer tap but with the addition of PH balanced, limescale-free, filtered cold water and filtered steaming hot water, meaning you can make the perfect cup of tea in an instant. Capable of delivering more than 100 cups of tea per hour, the steaming hot water is delivered safely by the use of an innovative child safe magnetic HotFob placed on the front of the tap. These beautifully engineered taps are available in two styles – Modern and Traditional – not only do they perform brilliantly and look stunning, there's also a design that's perfect for every kitchen style.



AGA 4-in-1  
Traditional Tap in  
Brushed Nickel Finish

[agaliving.com](http://agaliving.com)



## STOVES

### Cosy warmth, exceptional design.

AGA stoves are brought to you by the manufactures of the world famous AGA range cooker. For over 80 years AGA has remained at the forefront of engineering excellence and AGA stoves embody the best AGA traditions and employ the very latest technology.

The range includes solid fuel and wood burning models and includes a wide variety of styles to suit all tastes, from traditional to cotemporary.



Ludlow



Dorrington



[agastoves.co.uk](http://agastoves.co.uk)



Station Road  
Ketley  
Telford  
Shropshire  
TF1 5AQ  
England

E-mail: [customerrelations@agarangemaster.co.uk](mailto:customerrelations@agarangemaster.co.uk)  
Consumer Services Tel: **01952 643149**

**agaliving.com**

For ROI Enquiries Tel: 01 663 6166  
For International Enquiries Tel: +44 (0) 115 946 6138



Follow us:



Registered in England and Wales. Registration No. 354715 Registered Office: Meadow Lane, Long Eaton, Nottingham, NG10 2GD

AGA continuously seeks improvements in specification, design and production of products and thus, alterations take place periodically. Whilst every effort is made to produce up-to-date literature, this booklet should not be regarded as an infallible guide to current specification, nor does it constitute an offer for the sale of any particular appliance.

