





AGA TC3 (USA/CAN) HANDRAIL ASSEMBLY GUIDE



Before commencing fitment of the handrail to the AGA it must first be assembled.


Selecting the two vinyl end caps these must be positioned onto each end of the handrail. Next fit the handrail end brackets over the vinyl end caps, using a rotational motion to seat them fully. Once the assembly is complete it can now be slid into place over the handrail fixing studs which are already attached to the AGA top plate.



Once the handrail assembly has been positioned squarely onto the AGA the grub screws located on the underside of each handrail bracket can now be tightened using the 2.5mm allen key provided. This will lock the handrail assembly in place.




AGA TC3 (ÉTATS-UNIS/CANADA) GUIDE D'ASSEMBLAGE DE LA POIGNÉE



Vous devez assembler la poignée de la cuisinière AGA avant de l'installer sur la cuisinière.

Placez les deux capuchons en vinyle à chaque bout de la poignée. Ensuite, placez les deux supports sur les capuchons en vinyle, en les tournant pour les pousser bien en place. Une fois l'assemblage terminé, la poignée peut être mise en place sur les goujons d'assemblage déjà installés sur la plaque supérieure de la cuisinière AGA.



Une fois la poignée bien en place et droite sur la cuisinière AGA, serrez les vis de blocage sous chaque support de poignée à l'aide de la clef Allen de 2,5 mm fournie. Cela verrouillera l'assemblage en place.