


REDFYRE CENTRAL-HEATING COOKER (OIL & GAS FIRED)

MODELS 60, 80, 100, 120

PARTS LIST




REDFYRE CENTRAL HEATING COOKER ---- TOP - PLATE & LIDS




REDFYRE CENTRAL HEATING COOKER ---- TOP - PLATE & LIDS

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1		LID ASSEMBLY COMPLETE	C602457
2		LID SEAL	C601482
3		SPRING HANDLE	C601478
4		HINGE BLOCK	98066
5		PIVOT BLOCK	C610786
6		SPRING	99848
7		TUBE	GZ1944
8		HINGE BLOCK BAR	99574
9		HAND RAIL BRACKET (L. HAND)	98076L
10		HAND RAIL BRACKET (R.HAND)	98076R
11		HAND RAIL	C600841
12		HOT -PLATE COVER	C602664
13		FLUE SHROUD	C602663
14		HOTPLATE	C602662
15		HOTPLATE ROPE	n.c.a
16		TOP PLATE	C610214

REDFYRE CENTRAL HEATING COOKER ---- FRONT - PLATE & PANELS




REDFYRE CENTRAL HEATING COOKER ---- DOORS



REDFYRE CENTRAL HEATING COOKER ---- FRONT - PLATE, DOORS, PANELS

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1		SIDE PANEL (LEFT HAND)	C602701
2		SIDE PANEL (RIGHT HAND)	C602702
3		FRONT PLATE	C602800
4		DOOR CATCH PIN	C601581
5		R.H HINGE BLOCK	C602098
6		HINGE PIN	C330978
7		CATCH PLATE (OVEN)	C610174
8		DOOR CATCH (OVEN)	C602884
9		OVEN DOOR LINING (Early Models)	C602912
		OVEN DOOR LINING (Later)	C602970
10		OVEN DOOR SEAL	C602911
11		LINING SPRING (Early Models)	C602802
12		OVEN DOOR OUTER	C610220
13		CONTROLS DOOR LINING	C610176
14		DOOR CATCH (CONTROL/BURNER)	C602883
15		BURNER DOOR OUTER	C610220
16		GASKET (HINGE BLOCK)	C602974
17		DOOR CATCH SPRING	C602088
18		CONTROL DOOR OUTER	C610220
19		L.H.HINGE BLOCK	C602093
20		BUFFER	C99593
21		BURNER DOOR LINING	C602918
22		INNER DOOR PLATE	C610175
23		CATCH PLATE (Controls/Burner)	C610177
24		FRONT PLATE HINGE BLOCK	C601151
25		GASKET (FRONT PLATE)	C601157
26		NYLON WASHER	C93102
27		BACK PANEL	C602703
28		BASE PLATE	C602712


REDFYRE CENTRAL HEATING COOKER ---- CONTROL PANELS



2 REDFYRE CENTRAL HEATING COOKER ---- CONTROL PANELS

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1		BURNER RESET PANEL (GAS)	C603362
2		BURNER RESET SWITCH (GAS)	C603350
3		TTB RESET PANEL (Gas)	C603339
4		TTB DEVICE	C603351
5		BURNER RESET PANEL (OIL)	C602893
6		TIMER PANEL:	C602897
7		TIMER	C602209
8		CONTROL PANEL	C603374
9		NEON RED	C96455
10		NEON ORANGE	C96456
11		PUMP OVERUN THERMOSTAT	C602687
12		BOILER THERMOSTAT	C602685
13		BOILER OVERHEAT THERMO- STAT	C602686
14		OVEN THERMOSTAT (GAS)	C610777
14		OVEN THERMOSTAT (OIL)	C602906
15		OVEN OVERHEAT THERMOSTAT	C602905
16		THERMOSTAT KNOB	C602943
17		UPPER AIR TUNNEL	C602997
18		TIMER COVER	C602708



REDFYRE CENTRAL HEATING COOKER ---- COOKER BURNER (OIL)



REDFYRE CENTRAL HEATING COOKER ---- COOKER BURNER (OIL)

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1	n/a	COOKER BURNER COMPLETE	C602921
2	R2332	OIL PUMP (COOKER) BFP21RS	RO4M999145
3	R2333	SOLENOID COIL	RO4M999146
4	R2325	HOSE	RO4M999159
5	R2331	MOTOR (COOKER)	RO4M999147
6	R2330	IGNITION UNIT (COOKER)	RO4M999148
7	R2512	CONTROL BOX TF830.3	RO4M999376
8	R3978	PHOTOCELL	RO4M998284
9	R2321	BURNER MOUNTING GASKET	RO4M321149
10	R3673	BLAST TUBE (COOKER)	RO4M998262
11	R2335	ELECTRODE	RO4M998464
12	n/a	NOZZLE (COOKER) .5 x 60 EH	C610447
13	R3935	CONTROL BOX BASE	RO4M998383
14	R5323	FAN	RO4M998993
15	R2368	PUMP COUPLING	RO4M999257
16	R5797	IGNITION LEAD	RO4M998272
17	R2336	INNER ASSEMBLY	RO4M999156


REDFYRE CENTRAL HEATING COOKER ---- BOILER BURNER (OIL)



REDFYRE CENTRAL HEATING COOKER ---- BOILER BURNER (OIL)

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1	n/a	60K BOILER BURNER COMPLETE	C602922
1	n/a	80K BOILER BURNER COMPLETE	C602923
1	n/a	100K BOILER BURNER	C602924
1	n/a	120K BOILER BURNER	C602925
2	R5857	OIL PUMP BOILER BFP11R3	RO4M997984
3	R2333	SOLENOID COIL	RO4M999146
4	R2325	HOSE	RO4M999159
5	R2331	MOTOR (60 80 BOILER) 90W	RO4M999147
5	R5322	MOTOR (100 120 BOILER)	RO4M998929
6	R4666	IGNITION UNIT (BOILER)	RO4M998565
7	C610346	CONTROL BOX TF830.3	C610346
8	R3978	PHOTOCELL	RO4M998284
Not Shown	n/a	BURNER MOUNTING GASKET	C602979
10	n/a	BLAST TUBE (60 & 80K BOILER)	C610465
10	n/a	BLAST TUBE (100 / 120K BOILER)	C610425
11	R2335	ELECTRODE	RO4M998464
12	R3557	NOZZLE (BLR 60K) .60 X 80EH	RO4M998078
12	n/a	NOZZLE (BLR 80K) .75 x 80EH	RO4M997155
12	R3772	NOZZLE (BLR 100K) .85 X 80 EH	RO4M998395
12	R5248	NOZZLE (BLR 120K) 1.10 X 80EH	RO4M997099
13	R3935	CONTROL BOX BASE	RO4M998383
14	C603391	FAN (60 BOILER) 99 x 43mm	C603391
14	C603392	FAN (80 100 BOILER)120 x 50mm	C603392
14	C603393	FAN (120 BOILER) 124 x 60mm	C603393
15	R2368	PUMP COUPLING	RO4M999257
16	R5797	IGNITOR LEAD	RO4M998272
17	R2336	INNER ASSEMBLY	RO4M999156
18	n/a	REAR DISC	NCA
19	n/a	AIR DAMPER	NCA
20	n/a	AIR CONVEYOR	NCA
21	n/a	COVER AIR INLET	NCA
22	n/a	DIFFUSER (120 BOILER)	NCA


CENTRAL HEATING COOKER --- COOKER & BOILER BURNERS (GAS)



CENTRAL HEATING COOKER --- COOKER & BOILER BURNERS (GAS)

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1	C603380	BURNER HEAD --- COOKER	C603380
1	n/a	BURNER HEAD --- BOILER	C603381
2	R5601	IONISATION PROBE & LEAD	RG4M997505
3	C603383	IGNITION ELECTRODE	C603383
4	C603384	IGNITION ELECTRODE LEAD	C603384
5	C603385	IGNITION CONTROL BOX	C603385
6	C603386	BURNER GASKET --- COOKER	C603386
6	C603387	BURNER GASKET --- BOILER	C603387
7	n/a	MANIFOLD --- COOKER	C603388
7	C603389	MANIFOLD --- BOILER	C603389
8	C603390	FAN GASKET	C603390
9	C603391	FAN --- COOKER	C603391
9	C603391	FAN --- 60 BOILER	C603391
9	C603392	FAN --- 80, 100 BOILER	C603392
9	C603393	FAN --- 120 BOILER	C603393
11	C603395	GAS VALVE & VENTURI	C603395
12	C603396	BURNER MOUNTING GASKET (CKR)	C603396
Not Shown	C603397	BURNER MOUNTING GASKET (BLR)	C603397
Not Shown	n/a	FLEXIBLE GAS PIPE & SEAL	C603347
Not Shown	n/a	GAS PIPE SEAL ONLY	NYA


REDFYRE CENTRAL HEATING COOKER --- BOILER ASSEMBLY



REDFYRE CENTRAL HEATING COOKER --- BOILER ASSEMBLY

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1	n/a	BOILER ASSEMBLY	C602791
2		BOILER BURNER GASKET	C602979
3		ACCESS DOOR	C602842
4		ACCESS DOOR SEAL	C602844
5		ACCESS DOOR INSULATION	C602845
6		TOP BAFFLE (GAS) (MODEL 60 --- 2 OFF (MODELS 80, 100, 120 --- 3 OFF)	C602831
6		TOP BAFFLE (OIL) --- (ALL OIL MODELS --- 2 OFF)	C610400
7		BOTTOM BAFFLE (1 OFF (GAS))	C602825
7		BOTTOM BAFFLE (1 OFF (OIL))	C610398
8		CERAMIC BAFFLE (OIL ONLY 2 OFF)	C610403
9		ROPE SEAL 16mm	D22197


REDFYRE CENTRAL HEATING COOKER --- OVEN ASSEMBLY



REDFYRE CENTRAL HEATING COOKER --- OVEN ASSEMBLY

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1		COMBINED OVEN ASSEMBLY	C610215
2		BOTTOM OVEN TUNNEL	C601725
3		TOP OVEN TUNNEL	C602780
4		FLAT SEAL	FA0441
5		BOTTOM THERMOSTAT COVER	C610028
6		UPPER THERMOSTAT BRACKET	C602696
7		OVEN SERVICE HATCH	n/a
8		OVEN SERVICE HATCH GASKET	C98235
9		SERVICE HATCH COVER (GAS)	C610459
9		SERVICE HATCH COVER (OIL)	C602711
10		BURNER BOX COVER (GAS)	C610450
10		BURNER BOX COVER (OIL)	C602860
11		HOTPLATE BAFFLE	C603271
12		INSULATION COVER	C602808
13		INSULATION BOARD	C602936
14		FLUEWAY BAFFLE (GAS ONLY)	C610776
15		FLUEWAY BAFFLE (OIL ONLY)	C602737
16		FLUE MANIFOLD	C603375
17		SERVICE COVER	C602938
18		GASKET	C602935
19		FLUE STAT PIPE TOP (GAS ONLY)	C603378
20		FLUE STAT PIPE BOTTOM (Gas)	C603379
21		FLUE STAT PIPE GASKET (Gas)	C603358
22		DOG BONE FIXING KIT	C610597

CENTRAL HEATING COOKER --- COOKER COMBUSTION CHAMBER



CENTRAL HEATING COOKER --- COOKER COMBUSTION CHAMBER

ITEM no.	CAT No.	DESCRIPTION	PRODUCT CODE
1		FRONT BRICK	C602733
2		REAR BRICK	C602733
3		FRONT INSULATION	C610132
4		REAR INSULATION	C602982
5		L/H BRICK	C602732
6		L/H INSULATION	C602983
7		R/H BRICK	C602731
8		R/H MIDDLE INSULATION	C602792
9		R/H INNER INSULATION	C602984
10		BOTTOM INSULATION COVER	C602902
11		INSULATION SUPPORT	C602861

REDFYRE CENTRAL HEATING COOKER ---- ACCESSORIES

		FLAT BAKING TRAY WIRE OVEN SHELF FULL SIZE BAKING TRAY ROASTING DISH WIRE RACK HOTPLATE LIFTING TOOL FLUE CLEANING BRUSH	C600566 C610095 C610334 C600808 C602862 C602715 C602986