

IMPORTANT PRE-INSTALLATION CHECKLIST - AGA e7i **(model numbers 100 / 150 / 160 / 210)**



This pre-installation checklist is designed to highlight the necessary work needing to be completed prior to the delivery and connection of your AGA appliance. It should be used alongside the installation instructions for the appliance and AGA's pre connection video information to ensure successful delivery and connection.

Please ensure you advise the AGA Showroom of any potential issues that may prevent successful delivery and connection of your AGA as we may need to ask you for additional information.

Customer Reference	
Site Address:	Customer Name:
	Telephone No:
	Mobile No:
	Email:
	Key Contact for Site:
Postcode:	Key Contact No:

Checklist	Questions	Y	N	Remarks
Access and parking	Can the property be accessed by a 7.5 tonne lorry with a tail lift 2415mm (8ft 3in) wide? If a standard refuse vehicle can reach your property we should be able to also. Are there any special permissions or permits required to park outside your delivery address?			
Route for delivery	Is there a clear route into the kitchen? - The minimum gap needed is 750mm (30in) through doors and hallways. - Please give details or any steps, gravel areas, grass areas, uneven surfaces, obstacles, tight turns. Is any floor protection needed? Will there be any additional manpower on site when we arrive?			
Floor	What flooring will be under the cooker position? The cooker base must be level and flat and no lower than the finished floor. Please lay your flooring before the cooker is fitted or fit a suitable plinth to bring it level. The flooring must be capable of holding the weight of the cooker. <i>The cooker base dimensions, weights and clearances can be found on pages 4-6 of your installation instructions.</i>			

Position	Will the cooker be positioned between base units? Will the cooker be positioned against a clear wall? If so, please ensure this is marked to enable us to correctly position the cooker. Will the cooker be going into an alcove or recess? If so, electrical points cannot be located above or behind the cooker. They must be outside of the recess following the distances advised in our instructions. Is there space for a 3mm gap to be left each side of the cooker top plate? A 650mm space should be allowed above the hob area of the cooker to enable the insulated lids to be raised easily. Is the cooker going against a side wall? If so, additional clearances will be needed. <i>The cooker dimensions and clearances can be found between pages 4-6 of the installation instructions.</i>			
Rear wall	Is the rear wall clear of pipes, wires, drains and other services? There can be nothing directly above or behind the cooker position. Any services will need to be either re-routed or sunk into the wall. How much gap should be left behind the cooker position? A minimum gap of 10mm is required between the cooker and the surface behind. If this is to be increased, then please inform us prior to delivery or advise the delivery team on the day. If you are fitting a splash back or tiles after the cooker installation the thickness of this plus any adhesive should be factored into the gap measurement.			

Worktop	Will your surrounding work surfaces match the cooker height? The cooker hotplate is 915mm off the finished floor. The cooker dimensions can be found between pages 4-6 of the installation instructions. <i>Should the AGA eR7i be installed on a plinth / hearth to increase overall height of the appliance to match adjacent units it should be noted that any future service or repair work may require a two-person team to maneuver the appliance.</i>			
Electrics	Where are you planning on positioning your electrical connections?			
Ovens & Hotplate	The AGA requires a 32amp cooker switch within 2m either side of the cooker in the same room. This cannot be located above or behind the cooker position. This then connects to a 45amp outlet plate within 1.5m of the rear bottom right corner or 1.2m of the rear bottom left corner on eR7 100 models (0.7m of the rear bottom left corner on eR7 150 models) Once this is prepared by your electrician the power cable supplied with the cooker connects into the outlet plate.			
Induction Unit	The AGA requires a 13amp connection within 80cm of the rear bottom left corner or 100cm of the rear bottom right corner. This can either be a switched fused spur or a plug socket. Please note a plug is not supplied with the AGA. <i>Full details of this can be found on page 7 & 9 of the installation instructions.</i>			

Additional electrics are required for the eR7-150 and R7-210 models to power the additional 'hot cupboard' unit. The fuse rating will change depending on the hob option you choose. Additional electrics are required for the eR7-160 and eR7-210 to power the additional 'Module' conventional cooker unit.				
Warming Plate Hote Cupboard models	If you are having a warming plate, you will also need an additional 3amp supply. This will be a 13amp switched fused spur containing a 3amp fuse within 1.2m of the rear bottom left corner.			
Induction Hot Cupboard models	If you are having an induction unit you will also need an additional 13amp supply. This will be a 13amp switched fuse spur within 1.2m of the rear bottom left corner. <i>Full details of this can be found on page 7 & 9 of the installation instructions.</i>			
Integrated Module – eR7 160 and eR7 210	The module requires a 32amp electric connection on a minimum 6mm cable feed from the consumer unit. The isolation switch for this must be located within 2m of the cooker, be in the same room and not be located above or behind the cooker. <i>Please check your installation instructions for details on outlet plate location as this varies depending on whether you opt for a 160 or 210 model.</i>			
Gas Supply (Gas Hob Module)	If you opt for a module with a gas hob you will need the following gas connection: You will require a capped 15mm supply terminating behind the module. This must be located 840mm from your finished flooring and 60mm from the left-hand side of the module.			

Occasionally certain circumstances may dictate that we will be unable to deliver your product using our standard delivery service. Should an external specialist team be required we will advise you in advance of any additional costs you may incur before we proceed with your delivery.

A copy of this delivery and installation checklist should be returned to your store at the time of placing your order. Please retain a copy to assist you with preparing for your AGA installation.

If you have any queries once your order has been placed, please feel free to call our installations team for further assistance.

The team can be contacted **Monday-Friday 9am till 5pm** on **01952 643 534**

To assist you further you can view our pre-installation videos by selecting the correct model in the link [here](#).

If a delay is required to your installation date, we need a **minimum of five working days' notice before the agreed date**. Failure to provide this notice may incur a charge.

Please provide any additional information which may be relevant to the delivery or installation of the appliance